

CONTENTS

INTRODUCTION	1
General View	3
Power Supply	4
Initialization	5
Keyboard	6
Display	7
Main Menu	8
DICTIONARY	8
SUPPLEMENTAL DICTIONARIES	11
User's Dictionary	11
Military Dictionary	12
GRAMMAR	12
PHRASEBOOK	12
IRREGULAR VERBS	13
POPULAR IDIOMS	13
PHONES	14
SCHEDULE	14
CALCULATOR	16
METRIC CONVERSION	16
CURRENCY CONVERSION	16
HANGMAN WORD GAME	17
WORLD TIME	17
LOCAL TIME	18
PC-LINK	18
SETUP	19
Interface language	19
Advanced search	20
Slang lock	20
Russian keyboard mode	20
Key tone	20
Clock	20
Date format	21
Time format	21
Schedule alarm	21

Daily alarm	21
Memory check.....	21
Data deletion	22
Set password	22
Security mode	22
Set contrast.....	23
Speech options	23
Set sleep time	23

INTRODUCTION


Congratulations on purchasing the Partner® AzER430T! This product is the result of the combined efforts of Ectaco's linguists, engineers, and programmers, and represents the last generation of the highest-performance integrated educational tools available.

The Partner® AzER430T features:

- ❖ *Main vocabulary (English ↔Azeri, English ↔Russian, Azeri ↔Russian bidirectional dictionaries) of approx. 650,000 words, including medical, technical, legal, business, and more than 12,000 oil terms, as well as slang, idioms, and general expressions*
- ❖ *Electronic English Grammar book*
- ❖ *A selection of the most popular American idioms*
- ❖ *English irregular verbs*
- ❖ *12-topic book of common English phrases*
- ❖ *Advanced English and Russian speech synthesis*
- ❖ *Recording function for new words*
- ❖ *Instant reverse translation*
- ❖ *Award-winning Vector Ultima™ trilingual spell-checking system*
- ❖ *128K English/Azeri/Russian personal organizer for scheduling and telephone numbers, equipped with search function*
- ❖ *Metric and currency converters*
- ❖ *Local and World time*
- ❖ *High-speed data exchange with a PC*
- ❖ *Trilingual interface*
- ❖ *Russian Standard and Phonetic keyboard layouts*
- ❖ *Data protection system*
- ❖ *Slang lock*
- ❖ *External power jack for AC operation*
- ✓ *As continuous efforts are made by the manufacturer to ensure the best quality and performance of the Partner® products, some characteristics of the device you have purchased may slightly differ from their description in this manual.*

General View

The general view and external features of the AzER430T are shown below.



Power Supply

The AzER430T is powered by two AAA (LR03) batteries.

When the batteries become weak, a warning message will be displayed.

In order to prevent excessively discharging the batteries and undergoing a resulting loss of data in RAM, the Say function will be disabled if battery power is low. To restore full functionality of the device and to avoid risk of losing user data, replace the complete set of batteries as soon as possible. Do not mix old and new batteries.

- ✓ If you plug in the AC adapter, full functionality of the device will be restored during 1 minute.

How to replace the batteries

- Ensure the power is off. Press ON/OFF to turn the device off.
- ✓ Never try to remove batteries from the device when the power is on. This can seriously damage the device. If you experience difficulty turning the device off, press the RESET button on the right-hand side of the keyboard (over the O button) and reset the system.
- Remove the battery compartment cover by sliding it away from the device.
- Remove the used batteries and replace them with new ones.
- ✓ When replacing the batteries, you have 2 minutes to place new ones in the device without risk of losing any data stored in RAM. **Do not exceed the 2-minute limit!** Neither the manufacturer nor the dealer may be held responsible for loss of user data.
- Make sure to place the batteries according to the polarity marks (+ -) inside the compartment.
- Replace the battery compartment cover by sliding it toward the device. Make sure the cover sits in place properly.
- ✓ The AzER430T is equipped with a jack for external power supply.
- ✓ **Use of an inappropriate external power supply may cause failure of the device and may void the warranty.** The AC/DC adapter should provide 6V and min 300mA DC.
- ✓ Communication with a PC consumes a considerable amount of energy. Always try to use an external power supply during these operations.

Initialization

The initialization routine is started

- when AzER430T is turned on for the first time;
- when you remove the batteries (e.g. during replacement);
- after the system has been reset with the RESET button.
- ✓ The RESET button is located on the right-hand side of the keyboard (over the O button). It can be accessed with any thin object like a paper clip. Never use a needle or pin for this purpose since it can damage the device.
- If you see *Initialize system?(y/n)*, press the N button to abort initialization and customization.
- Then you will see the *Delete user's data?* message. Press the N button to save your data.

The *System initialized!* message indicates that system initialization has been completed and the factory defined default settings have been restored.

Keyboard

The standard American QWERTY keyboard is combined with Azeri and Russian standard layouts.

To enter the letters marked at upper left of the buttons, press ALT+ the desired button.¹

To enter such letters in caps, press SHIFT+ALT+ the desired button.

The AzER430T features standard and phonetic modes of entering Russian letters:

Russian standard mode allows you to enter Russian letters corresponding to the keyboard marks.

Russian phonetic mode allows you to enter Russian letters by their phonetic consonance with English letters, e.g. you can press the F button to enter the Russian letter “Ф”.

The table below shows the Russian and English layouts in the Russian phonetic mode.²

q	w	e	r	t	y	u	i	o	p
я	ш/щ	е/э	р	т	ы	у/ю	и	о	п
a	s	d	f	g	h	j	k	l	
а	с	д	ф	г/ж	х	й	к	л	
	z	x	c	v		b	n	m	
	з	ь/ъ	ц/ч	в		б	н	м	

- ✓ Unlike PC keyboards, there is no need to keep a key (such as SHIFT) down while pressing another one. It is enough to press it only once and release. The available set of national characters is dependent on which language input mode is selected. Language modes can be toggled by pressing the ⇄ button. ENG, AZ, or RUS is displayed in the upper right corner respectively.

Function shortcut keys












ON/OFF	Turn the device On or Off
RESET	Re-initialize system
SPELLER (SHIFT+ ▼ or ▲)	Launch spell-checker

Other shortcut keys open sections corresponding to the marks over the buttons (press SHIFT+ shortcut key; for example, SHIFT+DICT).

¹ Key1+Key2 here and further on signifies the combination of keys to use - first press and release Key1, then press and release Key2.

² Press ALT to enter letters shown after the slash (/) in the table.






Control and edit keys



	Move cursor / highlight / switch main menu
	Highlight / scroll lines / switch main menu/ change values. Use  to switch between the Insert and Overwrite modes.
	Scroll pages
ENTER	Execute
	Enter space
ESC	Close active window / cancel / return to the previous page
ALT	Enter symbols marked above the keys
SHIFT	Type in uppercase
 BS	Delete character to the left of the cursor
	Switch translation direction
SHIFT+ 	Open additional symbols ³
SHIFT+ 	Open record to edit
SHIFT+BS	Delete record
	Pronounce English or Russian headword
SHIFT+ 	Pronounce English or Russian translation
A, P	Specify AM or PM (when the 12-hour format is set)

Display

Partner® AzER430T features a high-resolution screen (160x64 pixels).

The indicator line is at the top of the display and shows the following indicators:

EDIT	Current Record opened in the edit mode
SHIFT	SHIFT key pressed
INS	Insert mode selected
	Batteries low
	Device locked
	Alarm on
	Vertical scrolling or paging enabled (more text available)
	Horizontal scrolling enabled

















³ Press ,  to move between the three lines of symbols. Press the corresponding number button to enter the desired symbol.

Main Menu

The AzER430T MAIN MENU consists of 16 functional icons, which visually organize access to the dictionary's sections.

- To display the MAIN MENU, turn the device on, or close a current section.
- Move between icons using ↓, ↑ or ←, →.
- To open a section, whose icon is highlighted, press ENTER.

The icons shown in the MAIN MENU represent the following sections:

	Dictionary		Calculator
	Supplemental Dictionaries		Metric Conversion
	Grammar		Currency Conversion
	Phrasebook		Hangman Word Game
	Irregular Verbs		World Time
	Popular Idioms		Local Time
	Phones		PC-Link
	Schedule		Setup

DICTIONARY

The *Dictionary* section includes English ↔ Azeri, English ↔ Russian, and Azeri ↔ Russian bidirectional dictionaries.

- Press SHIFT+DICT to enter the *Dictionary* section.
- ✓ Following system initialization, the English-Azeri dictionary is selected by default.

Viewing entries

- To view a translation of a word, enter it from the keyboard.

```

English⇒Azeri
dictio|
dictionary

```

- If the *Advanced Search* mode is turned ON, the headword closest in spelling to the portion you have entered so far will be displayed under the input line. When the desired word is displayed, press ENTER to see its translation(s).

- ✓ If the *Advanced Search* mode is OFF, your *Dictionary* work will be faster (see Page 20).

```

dictionary
[A]
lüğət;
[N]
lüğət

```

Use:

- ↓, ↑ to scroll through the translations
- ▲, ▼ to switch between adjacent entries.
- Press ESC or any letter button to return to the input line and translate another word in the same dictionary.

You can change the translation direction by pressing ⇆.

- Press ALT+DICT hotkey to switch between English, Azeri, and Russian dictionaries.

Parts of Speech and Gender Labels

Translations of a headword are listed in the alphabetical order by part of speech.

A – adjective	ID – idiom	PHR – phrase
ABBR – abbreviation	INTRJ – interjection	PREF – prefix
ADV – adverb	N – noun	PREP – preposition
ART – article	NPR – proper noun	PRON – pronoun
AUX – auxiliary	NUM – numeral	SUFF – suffix
CONJ – conjunction	PART – particle	V – verb

Russian nouns are marked with gender and number labels.

F – feminine	MN – masculine or neuter
FN – feminine or neuter	MPL – masculine plural
FPL – feminine plural	N – neuter
M – masculine	NPL – neuter plural
MF – masculine or feminine	PL – plural
MFPL – masculine or feminine plural	

Instant Reverse Translation

For your convenience, the AzER430T provides an *Instant Reverse Translation* for all words and expressions in the *Dictionary*.

- Press ←, → to select a word or expression for the reverse translation.

explanation [N] izah, izahat, şərh, açıqlama, anlatma, çözüm , aydınlaşdırma
--

- Press ENTER to obtain its instant reverse translation.
- You can make up to four reverse translations in succession (without closing windows). The message *Last translation* is displayed if the limit is reached.
- Use:

- ESC to close the *Reverse translation* windows⁴
- SHIFT+DICT or any letter button to return to the input line.

Spell-checker Vector Ultima™

When you are unsure of the spelling of a word, the multilingual spell-checker Vector Ultima™ will help you.





- Type the word as you hear it. For example, “foll” for “fall”.
- Press SHIFT+SPELLER (SHIFT and either of the ▲, ▼ buttons). A list of suggested variants appears on the screen.
- Select the desired word and press ENTER.
- ✓ If the spell-checker is unable to suggest alternative words, the *No variants* message is shown.

Pronunciation of words and sentences

The Text-To-Speech technology provides pronunciation of any English and Russian words and phrases.

- Display an entry.

Use:

-  to listen to the pronunciation of the headword
- SHIFT+ to listen to the pronunciation of all displayed translations.
- You also can listen to any selected words or phrases listed in the entry. Simply make the selection by using ←, → and press the  button.
- ✓ The device is able to generate pronunciation of any text, not limited to dictionary entries. Simply type a word or phrase in the input line of the corresponding *Dictionary* and press the  button to listen to its pronunciation.

⁴ The windows will be closed in the reverse order.

SUPPLEMENTAL DICTIONARIES

User's Dictionary

AzER430T allows you to create your own vocabulary.

- Enter the *User's Dictionary* subsection and choose one of the user's dictionaries – English, Azeri, or Russian.

Record

The record consists of a word or expression, its translation, and its part of speech. It also has information about the index number of the current record and the total number of records.

```
testify
[V]
dalalat etmek
[5/6]
```

Creating a Record


- When in a record list, press ENTER to open a new record template.
- ✓ If the dictionary is empty, a new record template will be opened automatically.
- Type in a word or expression. Press ENTER.

```
English word:      ENG
testify|
```

- Type in a translation(s). Use ⇔ to set the target language.

```
Azeri word:       AZ
dalalat etmek|
```

- Press ENTER again.
- Choose an appropriate abbreviation of the part of speech by scrolling by using ↓, ↑. Press ENTER.



The record will be saved and you will be returned to the records list.

Finding a Record

There are three ways to find a record:

- I. When in the record list, you may start typing the headword of a stored record. Use the Backspace key to delete the inputted word.
 - II. The records are sorted alphabetically by headword. You can scroll the record list by using ▼ or ▲.
 - III. Open the main dictionary, set the corresponding translation direction, type in a word saved in the user's dictionary and press ENTER.
- ✓ When *Security Mode* is ON, words from the User's Dictionary are not shown in the Main Dictionary.

Military Dictionary

This dictionary is highly useful for the squadron commanders, interrogation and intelligence specialists, military researchers and for the other military professionals. It contains additional 26,000 military oriented words and phrases related to the different aspects of defense activity: mine clearing, air and naval defense, marine activity, etc.

- Enter the *Supplemental Dictionaries* section.
- Choose the *Military Dictionary* icon.

Use the *Military Dictionary* in the same way as the *Main Dictionary* (see Page 8).

GRAMMAR

The AzER430T contains the *English Grammar* in the Russian language.

- Press SHIFT+GRAM to enter the *Grammar* section.

The *Grammar* contains three-level hierarchical menus. You can reach a menu's third level by consecutively selecting topics from the menu.

PHRASEBOOK

The phrasebook contains over 1,100 English phrases and their translations, divided into 12 conversational topics:

Everyday conversation	Shopping	Transport
Traveling	Sightseeing	Health

Hotel

Communication

Beauty care

In the restaurant

At the bank

Calling for police

Most of the topics contain a number of subtopics.

- Press SHIFT+PHRASES to enter the *Phrasebook* section.




- Select a topic. Press ENTER to see its subtopics.
- Use ⇔ to switch between Azeri and Russian translations.

IRREGULAR VERBS

All commonly used English irregular verbs are stored in alphabetical order in the *Irregular Verbs* section.

- Press SHIFT+VERBS to enter the *Irregular Verbs* section.
- Type the first letter of the desired verb and scroll through the list to find it.




- Use ⇔ to switch between Azeri and Russian translations.

POPULAR IDIOMS

Over 200 widely used American idioms and their equivalents or translations are included in the *Popular Idioms* section.

- Press SHIFT+IDIOMS to enter the *Popular Idioms* section.
- Type the first letter of the desired idiom and scroll through the list to find it.



- Use ⇔ to switch between Azeri and Russian translations.

PHONES

In this section you can store names, telephone and fax numbers, as well as postal and e-mail addresses in English, Azeri, and Russian.

- Press SHIFT+PHONES to enter the *Phones* section.

You will see a list of existing telephone records sorted by name.

```
Name:
Smith John
Phone:
+1-9999-999889999
[7/8]
```

Creating a Record

- To open a new record template, press ENTER when you are in the record list. If there are no records stored, a new record template will be opened automatically when you enter the list.
- Start filling out the *Name* page.
- ✓ If you have started typing in Azeri or Russian, then Azeri / English or Russian / English layouts are correspondingly available for further input.
- To open the next page, press ENTER.
- ✓ It is necessary to complete the *Name* page to continue to the subsequent pages.

Finding a Record

There are two ways to find a record:

I. When in the record list, you may start typing a name included in a stored record.

Use:

- BS to delete the inputted word
- ⇔ to switch between English, Azeri, and Russian input modes.

II. The records are sorted alphabetically by name. You can scroll the record list by using ▼ or ▲.

SCHEDULE

You may effectively manage your time by using the *Schedule* section.

- Press SHIFT+SCHEDULE to enter the *Schedule* section. The first of existing records will be shown.

Records are sorted by date and time.

```

Date: 2002/10/31 
Time: 14:40 10 min.
Content:
Meeting
1/4

```

- ✓ The check in the upper right corner indicates that the event occurred in the past.

Creating a Record

- To open a new record template, press ENTER when you are in the record list. If there are no records stored, a new record template will be opened automatically when you enter the record list.

```

Date:
2002/ 10/ 31
Time:
14:40
Reminder 00 min.

```

The first page of a record includes information on *Date*, *Time* and the audible *Reminder*. *Date* and *Time* specify the moment of the *Schedule alarm* operation. The *Reminder* specifies the time period until a *Schedule alarm* will be issued. The second page – *Content* – includes information about the event.

- Set the date and time and specify the time period until a *Schedule alarm* will be issued.
- Press ENTER to open the *Content* page and fill it out.
- ✓ If you have started typing in Azeri or Russian, then Azeri / English or Russian / English layouts are correspondingly available for further input.
- Press ENTER to save a record.
- ✓ The *Schedule* memory is limited to 50 records. The *Not enough memory* message is displayed when the record list is full.

Finding a Record

The records are sorted by date and time. Use ▼ , ▲ to scroll the record list.

Reminder and Schedule alarm

If enabled, the *Reminder* sounds at the determined time until a *Schedule alarm* will be issued, producing an audible beep. The *Reminder* is turned OFF by default for a new record. The *Reminder* time is adjusted separately for every individual record.

- ✓ *Reminders* and *Schedule alarms* sound even if the device is OFF.
- ✓ If a *Reminder* and a *Daily alarm* are timed to go off for the same time, only the *Reminder* will be displayed since it has higher priority.

The corresponding *Schedule* record will be displayed in the view mode at this time.

- Press any key to interrupt a *Schedule alarm* or a *Reminder* beep.

You can change the record and set the *Reminder* for a later time. Closing the *Schedule* reminder window will bring you back to the section (for example, *Dictionary*) as you were before the alarm went off.

CALCULATOR

- Press SHIFT+CALC to enter the *Calculator* section.

When entering numbers and operations from the keyboard, there is no need to press the SHIFT key while in the *Calculator* mode. Use this application as an ordinary pocket calculator.

METRIC CONVERSION

With the AzER430T you may easily convert measurements from the British-American system into the metric system commonly used in Europe and vice versa, as well as convert within each system.

- Enter the *Metric Conversion* section.
- Choose a subsection by pressing ↓, ↑. Press ENTER.
- Input the value.
- ✓ There may be more than four units of measure in the subsection.

CURRENCY CONVERSION

The *Currency Conversion* function allows you to instantly calculate conversion values between nine pre-installed currencies and three user-defined currencies.

- Enter the *Currency Conversion* section.
 - Setting and Checking Rates*
- Select the *Set rate* subsection to specify currency names and rates.
- Select a currency. Press ENTER.
- ✓ You can specify or change the names of any of the currencies listed. New currencies may be added in place of ???.
- Change/specify the currency name. Press ENTER to open the next window.
- Specify an exchange rate relative to the basic currency (whose rate should equal 1).
- ✓ The default exchange rate for all currencies is 1.

- Press ENTER to save changes.

Conversion

- Enter the *Calculation* subsection.
- Select a currency name and enter an amount.

While you are typing a new amount, the conversion is being performed.

HANGMAN WORD GAME

The AzER430T features the learning game *Hangman*, which can improve your spelling skills and enhance your personal vocabulary.

- Press SHIFT+GAME to enter the *Hangman* section.
- Select a language for the game. Press ENTER.
- Choose the target language by pressing ⇔.

Once the language is chosen, a new game will begin.

- Try to guess letters in the word by entering them from the keyboard. If you guess a letter correctly, it will appear in place of an asterisk in the word. The number displayed shows the number of tries remaining.

- When playing, press ENTER to display the translation of the hidden word (which will count as one try). To hide the translation, press ESC.
- Press the ◀ button to hear the hidden English or Russian word (counts as one try).
- After the game ends, the hidden word and its translation(s) will be shown.
- Press ESC to return to a new game.

WORLD TIME

Using the *World Time* section, you may view the current time in cities around the globe.

- Enter the *World Time* section.

```
World time
New York
USA
2002/11/14, Thu
18:06:31
```

The *World Time* screen shows the names of the selected city and country (default: New York, USA), the date, day of the week, and the current time for that city.

- To see information for another city, scroll through the alphabetic list by using ↓,↑.
- To see information for another city of the same country, scroll through the alphabetic list by pressing ▼, ▲.
- Also, you can quickly find a desired city by pressing the first letter of its name and scrolling through the list by using ↓,↑.
- When you find a desired city, press ENTER to save changes. The next time you enter this section the city you have chosen will be displayed first.

LOCAL TIME


- Press SHIFT+TIME to enter the *Local Time* section.

The *Local Time* screen shows the names of the selected city and country (default: Baku, Azerbaijan), the date, day of the week, and the current time for that city. You may specify these settings in the *Setup* section.

PC-LINK

Using the AzER430T *PC-Link* cable (available separately as part of the Communication Package) and the *PC-Link* software (included in the standard package on a CD-ROM) you may exchange data between your AzER430T and a personal computer. This feature will allow you to keep a backup copy of the *Telephones*, *Schedule*, and *User's Dictionaries* data on your PC.


Software

- Insert the supplied CD into the CD-ROM drive of a PC. If the installation program does not start automatically, run the INSTALL.exe file from the CD root catalog.
- Choose *AzER430T PC-Link* from the menu displayed on the PC.
- After the program is installed, start it from Start/Programs/Ectaco. The  icon will appear in the System Tray.
- ✓ The latest version of the *PC-Link* software and additional dictionaries can be downloaded from Ectaco's web site at www.ectaco.com

Sending and Receiving

- Connect the *PC-Link* cable to the *PC-Link* jack located on the right-hand edge of the device.
- Press SHIFT+PC-LINK to enter the *PC-Link* section.
- Right click the *PC-Link* icon in the System Tray. In the *PC-Link* program, select an appropriate data transfer mode.

- ✓ Make sure to select an appropriate COM port.
- ✓ Make sure you have no other *PC-Link* program running simultaneously with *AzER430T PC-Link*.
- Select the *Send data* transfer mode. Press ENTER.
- Choose the section(s) you wish to send. Use SPACE to check or uncheck a section.



- Press ENTER to start the transfer.
- ✓ Start the data transfer first on the receiving device, then on the sending device.
- To receive data, select the *Receive data* transfer mode. Press ENTER and the transfer will begin.
- ✓ The time span between the data transfer startup on the PC and the device must not exceed 30 sec.
- ✓ Note that in the *Receive data* mode, the newly transferred data will replace all the old information saved in the corresponding sections of your device. In case if empty sections are transferred, all data in the corresponding sections of the *AzER430T* will be erased.
- ✓ **Always back up your important data!** Neither the manufacturer nor the dealers assume any responsibility for lost or corrupted data.
- ✓ Data transfer consumes a considerable amount of energy. Using an external power supply is strongly advised.

SETUP

Personalize your AzER430T and ensure good maintenance of your personal records by selecting options in the *Setup* section.

- Press SHIFT+SETUP to enter the *Setup* section.

Most of the *Setup* section options are very easy to adjust. Unless stated otherwise, enter a subsection and select the desired option with ↓, ↑. Then press ENTER to confirm your choice.

Interface language

The default interface language of the AzER430T is English. You can switch interface language between English, Azeri, and Russian.

Advanced search

If the *Advanced search* mode is turned ON, the headword closest in spelling to the portion you have entered so far will be displayed under the input line. You can speed up your dictionary work by choosing to turn the *Advanced search* mode OFF. *Advanced search* is OFF by default.

Slang lock

In this subsection you can hide slang words or phrases contained in the dictionaries. For example, you may forbid your children access to slang. *Slang lock* is ON by default. To set *Slang lock* OFF, enter the **showslan** password and press ENTER.

Russian keyboard mode

In this subsection you can choose one of the available Russian keyboard modes: *Standard* or *Phonetic*.

Russian standard mode allows you to enter Russian letters in accordance with the keyboard marks.

Russian phonetic mode allows you to enter Russian letters by their phonetic consonance with English letters, e.g. you can press the F button to enter the Russian letter “Ф”.

Key tone


This feature is designed to produce a short beep every time you press a key on the device's keyboard. The key tone is turned ON by default.

Clock

In this subsection you can choose the city to display in the *Local Time* section and adjust the current time.


✓ January 01, 2003, 00:00 (12:00 AM), and Baku, Azerbaijan are the default values.

- Enter the *Clock* subsection.



- Specify the current date and time.
- Press ENTER to save changes.

The next section displayed will allow you to select the local city.



```
Baku
Azerbaijan
+04:00 (GMT)
```

This display shows the city and country names and the city's GMT offset. Refer to Page 18 to learn how to find the desired country or city in the list.

- When you find the desired city, press ENTER to save the changes.

Date format

The default Year-Month-Day date format can be changed to Day-Month-Year or Month-Day-Year.

Time format

The default 24-hour (Military) time format can be changed to the American 12-hour format.

Schedule alarm

In this subsection you can turn the *Schedule alarm* ON or OFF. If turned on, which is the default setting, the *Schedule alarm* will go off at the date and time of the *Schedule* record, producing an audible beep.

Daily alarm

- Enter the *Daily alarm* subsection.
- ✓ The default values are midnight, 00:00, and OFF.

Use:

- ←, → to switch between hours and minutes
- A, P to specify AM or PM
- ▼, ▲ to turn the alarm ON/OFF.
- Press ENTER to save changes.

If turned on, the *Daily alarm* produces a signal at the set time.

- Press any key to interrupt the *Daily alarm* beep (otherwise, the beep will continue for 30 seconds).

Memory check

Instantly check the free memory status with this *Setup* option.

- Enter the *Memory check* subsection to check the remaining free memory.

Data deletion

The *Data deletion* subsection gives you the ability to free up memory resources by deleting records much faster than removing them one by one.

Set password

With no password set (default) all functions of the AzER430T are freely accessible. After a password has been set, the following sections may be locked against unauthorized access: *Telephones, Schedule, User's dictionaries, PC Communication, Data deletion, Security mode, Set password*.

To gain access to any of these sections in the locked mode, a valid password must be provided.

- Enter the *Set password* subsection.

Input password

[* * * * * * * * |]

- Specify a password up to 8 characters in length. Press ENTER.
- Retype the password for confirmation. Press ENTER.
- ✓ Always remember your password. If you forget it, you will have to reset the system, which will cause irrevocable loss of user data.

Changing the password

- Enter the *Set password* subsection. Input the current password. Press ENTER.
- Specify a new password. Press ENTER.
- Retype the password for confirmation. Press ENTER to save the password.


Clearing the password

- Enter the *Set password* subsection. Input the current password. Press ENTER.
- Don't input any characters into next two fields, just press ENTER twice.

Security mode

With the help of the *Security mode* subsection you can protect your personal records and lock up the *PC communication* function.

- Enter the *Security mode* subsection.

When the ON option is selected, data access is locked and the  indicator is shown on the indicator line.

- ✓ It is recommended to close a password-protected section before you turn the device off.

The Security mode may be canceled by entering a valid password at the prompt when:

- the OFF option in the *Security mode* subsection is selected
- any protected section is opened.

Set contrast

The default contrast setting can be changed in the *Set contrast* subsection.

- Change the contrast level by using ←, →.

Speech options

Suit your own pronunciation by adjusting the speed and frequency of the built-in speech synthesizer.

Use ENTER to move between *Speech frequency* and *Speech speed* bars and ←, → to adjust the levels of each option.

Set sleep time

The automatic power off has a preset delay of 3 minutes. This feature saves battery life by shutting down the device after a specified period of inactivity. The adjustable range is from 1 to 5 minutes.