
FORWARD

Thank you for your purchasing our product. For best results and ensure that you are able to employ the features and functions of this product to their fullest, please read this manual carefully and keep it on hand for future reference.

IMPORTANT

You are strongly recommended to keep a separate record of all important data by other means to protect against its loss. We assume no responsibility for any damages or losses caused by deletion of data as a result of malfunction, repair or battery replacement. We also assume no responsibility for any loss or claim by the third parties, which may arise from the use of this product.

CONTENT

Chapter 1 Introduction.....	1
1.1 Brief of Function.....	1
1.2 Open and Close the Unit.....	1
1.3 About the Power Supply.....	1
1.4 Initialization.....	1
1.5 General Precautions.....	3
1.6 Automatic Power-off.....	3
1.7 Keyboard Layout.....	3
1.8 Main Menu.....	5
1.9 Specifications.....	7
 Chapter 2 Dictionary.....	 8
2.1 Eng-Viet Dictionary.....	8
2.1.1 Wisdom Search.....	8
2.1.2 General Search.....	9
2.1.3 Nearest Word and Spell Check.....	9
2.1.4 Wild Card Search.....	9
2.1.5 Cross Search with User's Dictionary.....	9
2.1.6 Cross Search with Viet-Eng or Eng-Eng Dictionary.....	10
2.1.7 Grammar Information Search.....	10
2.1.8 Repeat and Auto.....	12
2.2 Viet-Eng Dictionary.....	12
2.2.1 Wisdom Search.....	13
2.2.2 General Search.....	13
2.2.3 Nearest Word.....	14
2.2.4 Wild Card Search.....	14
2.2.5 Cross Search with User's Dictionary.....	14
2.2.6 Cross Search with Eng-Viet or Eng-Eng Dictionary.....	15
2.2.7 Repeat and Auto.....	15
2.3 Eng-Eng Dictionary.....	15
2.3.1 Wisdom Search.....	15
2.3.2 General Search.....	16

2.3.3	Nearest Word and Spell Check.....	16
2.3.4	Wild Card Search.....	16
2.3.5	Cross Search with Eng-Viet or Eng-Eng Dictionary.....	16
2.3.6	Repeat and Auto.....	16
2.4	Professional Dictionary.....	16
2.4.1	Choosing Categories.....	17
2.4.2	General Search.....	17
2.4.3	Cross Search with Eng-Viet, Viet-Eng and Eng-Eng Dictionary.....	17
2.4.4	Save for Revision Test.....	18
2.5	Practical Dictionary.....	18
2.6	Conversation.....	19
2.7	Revision Test.....	19
2.8	Phrasal Verbs.....	20
2.9	Viet Idioms.....	21
2.10	User's Dictionary.....	21
2.10.1	Data Entry.....	21
2.10.2	Data Viewing.....	22
2.10.3	Searching.....	22
2.10.4	Data Editing and Deletion.....	22
Chapter 3	Organizer.....	23
3.1	Telephone Directory.....	23
3.1.1	Data Entry.....	23
3.1.2	Data Viewing.....	23
3.1.3	Searching.....	24
3.1.4	Data Editing and Deletion.....	24
3.2	Memorandum.....	24
3.2.1	Data Entry.....	24
3.2.2	Data Viewing.....	25
3.2.3	Searching.....	25
3.2.4	Data Editing and Deletion.....	25
3.3	Schedule.....	25
3.3.1	Data Entry.....	26

3.3.2 Data Viewing.....	26
3.3.3 Searching.....	26
3.3.4 Data Editing and Deletion.....	26
3.4 To Do List.....	27
3.4.1 Data Entry.....	27
3.4.2 Data Viewing.....	28
3.4.3 Searching.....	28
3.4.4 Data Editing and Deletion.....	28
3.5 Calendar.....	28
3.6 World Time.....	29
3.7 Local Time.....	29
Chapter 4 Calculator.....	31
4.1 Simple Calculator.....	31
4.1.1 Arithmetic Calculation.....	31
4.1.2 Indices and Roots.....	31
4.1.3 Memory.....	31
4.2 Scientific Calculator.....	32
4.2.1 Arithmetic Calculator.....	32
4.2.2 Indices and Roots.....	32
4.2.3 Other Calculations.....	32
4.3 Unit Conversion.....	32
4.4 Currency.....	33
4.4.1 Currency Display.....	33
4.4.2 Rate Setting.....	33
4.4.3 Conversion.....	34
4.4.4 User Define.....	34
4.5 Loan Interest.....	34
Chapter 5 System.....	36
5.1 Reference.....	36
5.1.1 Maths Formaulae.....	36
5.1.2 English Name.....	36
5.1.3 Travel Guide.....	37

5.1.4	Size Equivalent.....	37
5.1.5	Voltage & Frequency.....	38
5.1.6	Telephone Code.....	38
5.2	Games.....	38
5.2.1	Hangman.....	38
5.2.2	Snake.....	39
5.2.3	Apple Chess.....	39
5.2.4	Shooting Game.....	40
5.3	USA Interview.....	40
5.4	Display.....	41
5.5	Memory Check.....	41
5.6	Data Deletion.....	41
5.7	PC Link.....	42
5.8	System Setting.....	42
5.8.1	Real Time Clock.....	43
5.8.2	Daily Alarm.....	43
5.8.3	Display Format.....	43
5.8.4	Sound On/Off.....	44
5.8.5	Speech Setting.....	44
5.8.6	Secret On/Off.....	45
5.8.7	Auto Power Off.....	45
5.8.8	Input Method.....	45
5.8.9	Repeat Setting.....	46
5.8.10	Chinese Display Mode.....	46

Chapter 1 Introduction

1.1 Brief of Function

This unit is a high-tech product designed to suit the fast moving society and to meet the increasing demand of consumer. There are various dictionaries in the unit: Eng-Viet, Viet-Eng, Eng-Eng, Professional Dictionary, Practical Dictionary, Conversation, Revision Test, Pharsal Verbs, Viet Idioms and User's Dictionary. User can choose any one of them for further reference. To help users to learn language more quickly and comprehensively, English and Vietnamese pronunciation are included too.

Other than dictionaries, the unit also provides Organizer, Calculator, Reference, Games, Data Communication, USA Interview, System Setting.

With these abundant and practical contents, users can handle daily business conveniently. And hence, their efficiency and effectiveness can be greatly increased.


1.2 Open and Close the Unit

To open the unit, hold it flat and press the front center button. Pull the cover up and adjust the angle, as you like. Close it until you hear a soft click.

1.3 About the Power Supply

The unit is powered by 2 AAA alkaline batteries. If it cannot be operated, does not work properly or a message "Low Battery" displays, please turn off the unit and replace the batteries with new ones. After battery replacement, the message "Please wait" will be shown, then the main menu will be displayed automatically.

1.4 Initialization

1. Press **RESET**  to reset the system without data cleared. Please

- note that the time or other settings may have been changed.
2. Press **RESET** and **Viet** button, the message "Initialize System?" will then appear, press (N) to ignore initialization; press (Y) to initialize the system with all user data being cleared.

Steps to Replace Batteries

1. Turn off the unit.
2. Unlock and then slide off the battery door.
3. Replace the old batteries with new ones (make sure the polarities are correct).
4. Cover and lock the battery door.

Note: The unit cannot be switched on unless the battery door is closed properly.

Cautions

1. Never leave dead batteries in the battery holder.
2. Always replace all 2 batteries at the same time.
3. Remove the batteries if the unit is not used for a long period of time.

Using AC Adaptor

1. Turn off the unit before unplugging or plugging the AC adaptor.
If the unit is not working due to improper operation, simply take out the batteries and replace them again.

2. Specifications of AC Adaptor

Hong Kong	Input:	AC220V,	50 Hz
	Output:	DC6V,	350mA
Vietnam	Input:	AC220V,	60Hz
	Output:	DC6V,	350mA
U.S.A.	Input:	AC110V,	60Hz
	Output:	DC6V,	350mA

Ensure that the local mains voltage in your location matches that of your adaptor.

1.5 General Precautions


- Keep the unit away from direct sunlight, heat, humidity and dust.
- Do not use or place the unit in very low or high temperature.
- Prevent the unit from dropping on the ground.
- Never use detergent, liquid cleansers or solvent (like gasoline) to clean the unit. Wipe the unit with soft and dry cloth.
- Avoid touching the screen with sharp-edged or angular objects.
- Do not twist or bend the unit.
- For safety, important data should be backed up by other means.
We take no responsibility for data loss due to improper use, replacement of batteries or other reasons.


1.6 Automatic Power-off

- The unit will automatically switch off after 3 minutes with no key activity. Press **⏻** to switch on the unit again.
- Even if the unit is switched off, it will switch on at alarm time.
- You can set the power-off period in System Setting.

(Please note that during input or edit, if no key is pressed for 3 minutes, the unit will also switch off automatically with the data kept.)

1.7 Keyboard Layout





1. LCD
2. (i) Pronunciation of Foreign Languages in Conversation
(ii) Change the Language in Conversation
3. Plurals
4. Repeat/Auto
5. Verb
6. Mark Record/Speed
7. Example
8. Power On/Off
9. Synonym
10. Antonym
11. (i) Switch between Vietnamese and English Input Modes
(ii) Switch the Display Language (in the Main Menu) between Vietnamese and English
12. Shift
13. (i) Switch between the 4 Main Menu
(ii) Return to Main Menu
14. (i) Clear Data
(ii) Return to Previous Screen
(iii) Set Alarm On/Off
15. Viet-Eng Dictionary Hot Key
16. Eng-Viet Dictionary Hot Key
17. New Function
18. Symbol
19. (i) Insert a Space
(ii) Set DST On/Off
20. (i) Confirm Input/Selection
(ii) "=" in Calculator

- 21.(i) Move Cursor to the Left
 - (ii) Delete Record
- 22.(i) Move Cursor Down
 - (ii) Edit Record
 - (iii) Vertical Scroll of Browse List
- 23.(i) Move Cursor to the Right
 - (ii) Insert a Character
- 24.(i) Move Cursor Up
 - (ii) Temporary Capital Letter Input Mode
 - (iii) Vertical Scroll of Browse List
- 25.Search Function/EXP
- 26.(i) Delete the Letter/Character before the Cursor
 - (ii) Local Time
- 27.Confused Word
- 28.Homonym
- 29.Next Record/Page
- 30.Previous Record/Page
- 31.English Pronunciation
- 32.Vietnamese Pronunciation
- 33.Run-Ons
- 34.Earphone Jack
- 35.Reset
- 36.Volume Record
- 37.Contrast Adjustment
- 38.Battery Lock
- 39.Data Link Jack
- 40.Adaptor Jack
- 41.Battery Holder

1.8 Main Menu

There are 4 main menus, which include Dictionary, Organizer, Calculator and System. And there are totally 30 main functions, which are represented by 30 icons.

The icons and what they represent are as follows:

A. Dictionary Menu



English-Vietnamese Dictionary



Vietnamese-English Dictionary



English-English Dictionary



Professional Dictionary



Practical Dictionary



Conversation



Revision Test



Phrasal Verbs



Vietnam Idioms



User's Dictionary

B. Organizer Menu



Telephone Directory



Memorandum



Schedule



To Do List



Calendar



World Time



Local Time

C. Calculator Menu



Simple Calculator



Scientific Calculator



Unit Conversion



Currency



Loan Interest

D. System Menu



Reference



Game



USA Interview



Display



Memory Check



Data Deletion




PC Link






System Setting

To Reach the Desired Main Menu

Press  or  or  to switch among the 4 main menus.

How to Reach the Desired Function

1. Press   to highlight the desired item and press .
2. Press the relevant numeric key directly to enter a function.

1.9 Specifications

LCD Size:	240 x 80 dots
Maskrom:	192M bits
Ram:	1M bits
Flash Memory:	2M bits
Battery:	AAA x 2

Chapter 2 Dictionary












2.1 Eng-Viet Dictionary

You can perform searching by entering the word or perform searching sequentially. The dictionary provides meanings of English words in Vietnamese. You can also view the grammar information like antonym, synonym, example, verb, etc. and hear the English and Vietnamese pronunciation. Auto and Repeat functions are also available in this section.


Two methods of searching are available. They are Wisdom Search and General Search. You only need to input an English word or phrase, then find out its meanings.

Choose "Eng-Viet Dict" from Dictionary main menu.


2.1.1 Wisdom Search

1. Enter the first letter of the word you want to search (e.g. "g").
2. The nearest word will appear on the screen.
3. Press   or   to search for the desired word sequentially.
4. You may also enter the remaining letters. (e.g. "go") Then the word will appear at the top of the list.
5. Press  to view its meanings.
6. Press   to view the preceding or following part of the same record, if any.
7. Press   to view the meanings of the previous or next record.
8. Press the pronunciation key to hear the English pronunciation of the headword.
9. Press the relative numeric keys to look for antonym, synonym, example, verb, etc., if "1", "2", "3", "4" appear at the right upper corner of the first row.
10. Press  to escape.

2.1.2 General Search

1. Enter the word or phrase and press .
2. View the meanings and the relevant grammar information or listen to the pronunciation of the headword by using the same approach mentioned above.



2.1.3 Nearest Word and Spell Check

If the inputted word is not in the dictionary, "Nearest Word" and "Spell Check" will be shown for selection after pressing . Select "Nearest Word" to display the word alphabetically nearest to the one inputted. Select "Spell Check" to display a list of words that are phonetically similar to the one inputted.



2.1.4 Wild Card Search


When you can only remember part of a word or a phrase, you can use "?" to replace an unknown letter, or "*" to replace several unknown letters. Relevant words or phrases will be displayed according to alphabetical order.

1. Enter the word you want to search (e.g. "bas?n" or "acc*ted").
2. Press  to perform searching.
3. Press  to look for the word you want.





2.1.5 Cross Search with User's Dictionary

If the meanings of the word entered exist in both the Built-in Dictionary and the User's Dictionary, you can choose either of them.












Note: When the word can only be found in User's Dictionary, its meanings found in User's Dictionary will be shown automatically.

1. Input a word and press . (e.g. "deliberate" which has been inputted in User's Dictionary).
2. "Built-in EV Dict" and "Built-in EV User's Dict" are shown on the screen.
3. Highlight "Built-in EV User's Dict" and press  to view the meanings in EV User's Dict.


2.1.6 Cross Search with Viet-Eng or Eng-Eng Dictionary

You can highlight any Vietnamese word to cross search with Viet-Eng Dictionary or highlight the headword to cross search with Eng-Eng Dictionary.





1. Press  to highlight the headword and press  to cross search with Eng-Eng Dictionary.
2. Press     to highlight a desired Vietnamese word.
3. Press  to perform cross search with Viet-Eng Dictionary.
4. Press  to escape.



dedicate
[ˈdedəˌket]
vt.
cống hiến.hiến dâng.đề tặng
(sách...)



cống
drain. sewer. offer as a
tribute.

Note: After highlighting a word, users can press , then  or  to highlight the word or words on its left/right side. Press  to cancel the highlighting scope.

2.1.7 Grammar Information Search

When you search for the meanings of a word, you can also find out relevant grammar information like synonyms, antonyms, examples, etc., provided that there is the relevant grammar symbol at the upper right corner. Cross search can be done and English pronunciation can also be heard when viewing the grammar information. These are represented by numbers which appear at the upper right corner.


1. Antonym
2. Synonym
3. Example
4. Verb
5. Plural
6. Run-On
7. Confused Word
8. Homonym

A. Antonym and Synonym


Antonyms or synonyms of a word can be searched if "1" or "2" appears at the upper right corner of the screen. "1" represents "Antonym" and "2" represents "Synonym". You can also search the meanings of antonyms and synonyms.

1. Enter a word and find its meanings.
(e.g. "admit")




```
admit
[əd'mit]
vt.
nhập vào .nhận được.(kỹ)quy
nạp
```

2. Press  to view its antonym.

```
<<Antonym>>
1.contradict
refuse
reject
```

3. Press  to view its synonym.

```
<<Synonym>>
1.acknowledge
answer
concede
recognize
```

4. Press  after highlighting to view the meanings of the desired antonym or synonym.
5. Press  for English pronunciation.
6. Press  to escape.

B. Example

The word you search is explained with an example if "3" is appeared at the right upper corner of the screen.

1. Enter a word and find its meanings.
(e.g."type")

```
<<Example>>
1.What type of room you want?
ông muốn loại phòng nào?
```


2. Press ^{Example} (3) to view its example(s).
3. Press ^{Cap} (A) ^{Edit} (V) to view the unshown part of example(s).
4. Press ^{Eng} (Eng) for English pronunciation.
5. Press ^{Enter} (=) after highlighting English word(s) to cross search with Eng-Viet Dictionary and Eng-Eng Dictionary.
6. Press ^{Clear} (C) to escape.

C. Plural

Plural of a word can be searched if "5" is shown at the upper right corner of the screen.

1. Enter a word and find its meanings.
(e.g. "type")

<p style="text-align: center;"><<Plural>></p> <p>Original : type</p> <p>Plural : types</p>
--

2. Press ^{Plural} (5) to view its plural.
3. Press ^{Eng} (Eng) for English pronunciation.
4. Press ^{Enter} (=) after highlighting English word(s) to cross search with Eng-Viet Dictionary and Eng-Eng Dictionary.
5. Press ^{Clear} (C) to escape.

Note: The operation of other grammar information search will be the same as above.

2.1.8 Repeat and Auto

Press ^{Auto} Repeat to perform repeat function, the record will be pronounced for 1-99 times depending on users' setting. Press ^{Clear} (C) to escape.

Press ^{Shift} (S) + ^{Auto} Repeat to perform auto-repeat function, the system will speak out the pronunciation of all records in the selected file. Repeat times depend on users' setting. Press ^{Clear} (C) to escape.

2.2 Viet-Eng Dictionary












Viet-Eng Dictionary provides meanings in English for Vietnamese words, and cross search with Eng-Viet and Eng-Eng Dictionary is

available. You can also listen to the pronunciation of Vietnamese and English words. Repeat and Auto functions are also available in this section.

Two methods of searching are available. They are Wisdom Search and General Search.


Choose "Viet-Eng Dict" from Dictionary main menu.

2.2.1 Wisdom Search

1. Enter the word you want to search.
2. The nearest word will appear on the screen.
3. Press   or   to look for the word sequentially or go on to enter the remaining part of the word. Then the word will appear at the top of the list.
4. Highlight or enter the word and press  to view its meanings.
5. Press   to view the preceding or following part of the same record, if any.
6. Press   to view the previous or next record.
7. Press  to hear the English pronunciation of the English meanings.
8. Press  to escape.


<VE>g_
1.gà
2.gà chót
3.gà ra
4.gá


2.2.2 General Search

1. Enter the word or phrase and press .
2. Follow the above approach to view the meanings and to listen to the pronunciation of the word or phrase.

2.2.3 Nearest Word

The nearest word to the word entered will be displayed when a word is wrongly entered or the word is not included in the dictionary.

1. Enter a Vietnamese word (which is wrongly entered) and press .
2. A message "Nearest Word!" appears on the screen.
3. The nearest word will then appear automatically.



2.2.4 Wild Card Search



You can use "?" to replace an unknown character or "*" to replace several unknown characters of an uncertain word. Relevant words will be displayed after searching.


(Refer to 2.1.4 Wild Card Search in Eng-Viet Dictionary.)

2.2.5 Cross Search with User's Dictionary

If the meanings of the word entered exists in both the built-in dictionary and the user's dictionary, you can choose either of them.


Note: When the word can only be found in User's Dictionary, its meanings found in User's Dictionary will be shown automatically.


1. Input a Vietnamese word which has been inputted in User's Dictionary and press .
2. "Built-in VE Dict" and "Built-in VE User's Dict." are shown on the screen.
3. Highlight "Built-in VE User's Dict." and press  to view the meanings in VE User's Dict..







2.2.6 Cross Search with Eng-Viet or Eng-Eng Dictionary


When you are viewing the English meanings of a Vietnamese word, you can highlight English word(s) to cross search with Eng-Viet or Eng-Eng Dictionary.


1. Press  to highlight the first English word.



ca
sing. mug. shift. team. case.

2. Press     to highlight the desired English word(s).

3. Press  to perform cross search with Eng-Viet or Eng-Eng Dictionary.



1 Eng-Viet Dict.
2 Eng-Eng Dict.

4. Press  to escape.

(Refer to 2.1.6 Cross Search with Viet-Eng or Eng-Eng Dictionary in Eng-Viet Dictionary for how to highlight more words.)

2.2.7 Repeat and Auto

(Refer to 2.1.8 Repeat and Auto in Eng-Viet Dictionary.)

2.3 Eng-Eng Dictionary

You can use Wisdom Search, General Search or Wild Card Search to look for the English meanings of English words and phrases. Cross search with Eng-Viet or Eng-Eng Dictionary and English pronunciation are also available. You can also carry out Repeat and Auto functions in this section.













Choose "Eng-Eng Dict." from Dictionary main menu.

2.3.1 Wisdom Search

1. Enter the first letter of the word you want to search (e.g. "w").
2. The nearest word will appear on the screen.



<EE>w_
1. w
2. wac
3. wacky
4. wad

3. Press   or   to look for the word sequentially.
4. Or you may enter the remaining letters (e.g. "wrong"). The relevant words will then appear on the top of the list.
5. Highlight the word and press , or press  after entering the word to view its meanings.
6. Press   to view the preceding or following part of the same record, if any.
7. Press   to view the meanings of previous or next record.
8. Press  to listen to the English pronunciation.
9. Press  to escape.

2.3.2 General Search

(Refer to 2.1.2 General Search in Eng-Viet Dictionary.)

2.3.3 Nearest Word and Spell Check

(Refer to 2.1.3 Nearest Word and Spell Check in Eng-Viet Dictionary.)

2.3.4 Wild Card Search

(Refer to 2.1.4 Wild Card Search in Eng-Viet Dictionary.)

2.3.5 Cross Search with Eng-Viet or Eng-Eng Dictionary

(Refer to 2.2.6 Cross Search with Eng-Viet or Eng-Eng Dictionary in Viet-Eng Dictionary.)





2.3.6 Repeat and Auto


(Refer to 2.1.8 Repeat and Auto in Eng-Viet Dictionary.)

2.4 Professional Dictionary












There are 9 Professional Dictionaries included, namely Computer, Construction, Economics, Electronics, Foreign Trade, Law, Mechanics, Medicine and Travel. General Search and Wisdom Search can be used to look up the Vietnamese meanings of English words and phrases. Cross Search with Eng-Viet, Viet-Eng and Eng-Eng Dict is also available.

2.4.1 Choosing Categories

1. Press   to turn pages up and down or press   to choose desired item sequentially for inquiry. (e.g. choose "computer")











2.4.2 General Search



1. Press   to turn pages up and down or press   to highlight desired word for inquiry or input the desired word directly.
2. For example, input "backlit" and press .
3. Press   to search sequentially.
4. Or press   for the rest of the record.
5. Press  for English pronunciation; and  for Vietnamese pronunciation.



2.4.3 Cross Search with Eng-Viet, Viet-Eng and Eng-Eng Dictionary

In Professional Dictionary, you can cross search with Eng-Viet, Viet-Eng and Eng-Eng Dictionary.

1. For example, input "backlit" and press .
2. Press  to highlight the first word.
3. Press     to choose the desired Vietnamese word.
4. Press  to highlight the word "cho".
5. Press  to cross search with the Viet-Eng Dictionary.



6. Press **Eng** for English pronunciation;
Viet for Vietnamese pronunciation.

cho
 give. bestow. offer. endow.
 for. to.

7. Press **C** **AC** to search the preceding and the next records. Press
Back **Edit** to view the unshown content of the same record.

8. In Viet-Eng Dictionary screen, you
 can highlight any English word(s)
 to cross search with Eng-Viet or
 Eng-Eng Dictionary.

1 Eng-Viet Dict.
 2 Eng-Eng Dict.

2.4.4 Save for Revision Test

Press **Speed** **Mark** to save some important/difficult words or phrases which
 are selected in Professional Dictionary for revision test.

2.5 Practical Dictionary

Practical Dictionary contains the meanings of general vocabularies
 categorized in different aspects.

1. Press **Back** **Edit** to choose the
 desired item and press **Enter =** to
 confirm.

A. FOOD & DRINK
 B. APPAREL
 C. HOUSING
 D. TRAFFIC
 E. ENTERTAINMENTS

2. For example, choose "Food & Drink".
 3. Choose "Vietnamese Cuisine".
 4. Input a word or highlight the word
 and press **Enter =**.




<PRACT>beef fondu_
 1.beef fondu
 2.beef noodle soup
 3.charbroiled ground shrimp on sugarcane
 4.charcoal grilled pork with vermicelli
 5.chicken noodle soup
 6.chicken salad
 7.chicken with lemon grass & hot pepper
 8.deer fried shrimp

5. Choose "beef fondu".
 6. Press **C** **AC** to search the previous or next record.
 7. Press **Eng** for English pronunciation; **Viet** for Vietnamese pronun-
 ciation.
 8. You can also carry out Repeat and Auto functions in this section.


*(Refer to 2.4.3 Cross Search with Eng-Viet, Viet-Eng and Eng-Eng
 Dictionary in Professional Dict.)*

2.6 Conversation







9 categories of daily conversation are listed for your daily life and travel. English, French, Mandarin, Cantonese, Spanish, Japanese, Italian, German, Dutch and Vietnamese are included with pronunciation.

1. Press   to choose the desired item sequentially and press  to confirm.

A. BASIC CONVERSATION
B. IMMIGRATION
C. HOTEL
D. IN THE RESTAURANT
E. SHOPPING





2. For example, choose "Basic Conversation".
3. Choose "Greetings" and press .

Bạn mạnh giỏi chú?
[E] How are you?

4. Press  to listen to the pronunciation of the current language. You can also press  for English pronunciation if the current language is English. Press  for Vietnamese pronunciation.
5. Press  +  to change the current language, then press the relevant numeric key to confirm, e.g. press  to choose Cantonese.

<<Languages>>
1 English
2 French
3 Mandarin
4 Cantonese

Bạn mạnh giỏi chú?
[C] 你好嗎?

6. Press   to inquire the previous and the next record.
7. Press  to highlight the first word, press  to cross search with Viet-Eng, Eng-Viet or Eng-Eng dictionary.
8. You can also carry out Repeat and Auto functions in this section.



Note: You can change the language by pressing the relevant English letters too. E for English, F for French, M for Mandarin, C for Cantonese, S for Spanish, J for Japanese, I for Italian, G for German and D for Dutch.

2.7 Revision Test

Revision Test consists of four sections, namely E-V Revision Test,

V-E Revision Test, E-E Revision Test and Prof. Dict. Revision Test.

Choose "Revision Test" from Dictionary main menu.

1. Highlight any one of the 4 tests and press . For example, highlight "E-V Revision Test" and press .




2. Press   to select test method, press  to confirm.

<<E-V Revision Test>>


1	Random
2	Sequential
3	Bottom-up
4	Continue


Please input answer:

adj.
(thực)chín cánh(hoa)

3. No matter right or wrong, press  to display the right answer.
4. Press  to view the next question.
5. Press  again to inquire the score.



2.8 Phrasal Verbs


1. Input the first letter, a browse list will appear. Highlight the desired item and press  to confirm or continue to input.

2. For example, input "make fun of " and press .

<PHRA>make fun of _


1.	make fun of
2.	make sure
3.	no matter
4.	on time
5.	out of order
6.	point out
7.	put up with
8.	quite a few

3. Press   to search the previous and the next record.

4. Press  for English pronunciation.

make fun of
The naughty boys like to make
fun of the old man.



5. Press     to highlight the desired word, then press












 to cross search with Eng-Viet and Eng-Eng Dictionary.

6. You can also carry out Repeat and Auto functions in this section.

2.9 Viet Idioms

Viet Idioms contain general idioms in Vietnamese with their meanings too.


1. Input the first letter, a browse list will appear. Highlight the desired item and press  to confirm or continue to input.






ác giã ác báo
lắm điều ác thì sẽ gặp ác
2. Press   to search sequentially or press   to view the unshown content of the same record.
3. Press  for Vietnamese pronunciation.
4. Press  to highlight the first word, then press     to highlight the desired word and press  to cross search with Viet-Eng Dictionary.
5. You can also carry out Repeat and Auto functions in this section.

2.10 User's Dictionary




There are three types of User's Dictionary: Eng-Viet, Viet-Eng and Eng-Eng. Users can input any English and Vietnamese word and its meanings for future reference in Eng-Viet, Viet-Eng or Eng-Eng User's Dictionary. Choose "User's Dictionary" from Dictionary main menu.

2.10.1 Data Entry


1. Choose Eng-Viet, Viet-Eng or Eng-Eng User's Dictionary in User's Dictionary submenu.

<<User's Dictionary>>
1 Eng-Viet User's Dictionary
2 Viet-Eng User's Dictionary
3 Eng-Eng User's Dictionary
2. Press  to go to the input screen.
3. Press   to select the field for input.
4. Input English or Vietnamese word and its meanings.
5. After inputting all data, press  to save.

2.10.2 Data Viewing




1. Highlight the desired word and press  to view its content.
2. Press   to view the previous or next record.

2.10.3 Searching





1. To search a record, press .

<<Keyword Search>>

Input Keyword:

2. Input the keyword of the desired record and press .
3. Press   to view the previous or next relative record.

2.10.4 Data Editing and Deletion


1. To edit a record, view it or highlight it and press  + .
2. To delete a record, view it or highlight it and press  + .

Chapter 3 Organizer






3.1 Telephone Directory

Telephone Directory contains data such as name, category, sex, telephone number and address. User can store telephone data anytime for further reference.


Select "Telephone Directory" from Organizer main menu.








There are 5 fields for data entry. The icons for data input are as follows:

-  Name
-  Category
-  Sex
-  Home Telephone Number
-  Home Address



3.1.1 Data Entry

1. Press  to create a new record.








2. Press  to choose English or Vietnamese input mode.
3. Press  to choose the input field.
4. In the Category and Sex items, press  to choose the other selections.
5. Press  to lock the record.

Note: You must set password in System Setting before locking records.


6. After data input, press  to save the record.
7. Press  to escape.

3.1.2 Data Viewing







1. Highlight the desired record in the browse list and press  to view its contents.

2. Press   to view the unshown content of the same record.
3. Press   to view the previous or next record.




3.1.3 Searching

1. To search record, press  to enter the search mode.





<<Search>>	
1	By Name
2	By Keyword

2. Press   to highlight "Keyword Search" or "Name Search" and press  to enter the relevant search mode.
3. Input the Name if you select to search by Name; or input the Keyword if you select to search by Keyword, and press  to confirm.
4. Press   to view relative records.

3.1.4 Data Editing and Deletion

1. To edit a record, highlight or view it and press  + . Press  after editing to save the record.

<<Telephone Directory>>	
alex	Delete record? Y/N
Simon	


2. To delete a record, highlight or view it and press  + .
3. Press  to delete or press  to retain the record.


3.2 Memorandum



This is a very powerful function of keeping notes. User can store, view, edit or delete the records at any time.

Choose "Memo" from Organizer main menu.



3.2.1 Data Entry

1. Press  to open a new record.






<div>  </div>
--

2. Press  to choose English or Vietnamese input mode.
3. Press  to lock the record.

Note: You must set password in System Setting before locking data.





4. After inputting data, press  to save the record.
5. Press  to escape.

3.2.2 Data Viewing

1. Highlight the desired record in the browse list and press  to view its contents.
2. Press   to view the unshown content of the same record.
3. Press   to view the previous or next record.







<<Memorandum>>	
2005.12.15 10am	go shopping
2005.01.01 13pm	have a party

3.2.3 Searching

1. Press  to enter keyword search mode.
2. Input the keyword of the desired record and press  to confirm.
3. Press   to view relative records.

<<Keyword Search>>	
Input Keyword:	

3.2.4 Data Editing and Deletion

1. To edit a record, highlight or view it and press  + . After editing, press  to save the record.
2. To delete a record, highlight or view it and press  + .
3. Press  to escape.





<<Memorandum>>	
2005.12.15 10am	go shopping
2005.01.01 13pm	have a party


3.3 Schedule

Schedule can save date, time, and content of appointments. It also has alarm function to remind users the appointment time.

Choose "Schedule" from Organizer main menu.


There are 4 fields for data entry. The icons for data entry are as follows:










-  Date
-  Time
-  Alarm Time
-  Content








3.3.1 Data Entry

1. Press  to open a new record.





2. Press  to choose English or Vietnamese input mode.
3. Press   to choose the input field.
4. Press  to lock the record.
5. In "Alarm Time" field, press  +  to enable the alarm.  will be shown to indicate the alarm is switched on.
6. After inputting data, press  to save the record.
7. Press  to escape.







3.3.2 Data Viewing

1. Highlight a record in the browse list and press  to view its contents.
2. Press   to view the unshown content of the same record.
3. Press   to view the previous or next record.



3.3.3 Searching


1. Press  to search record.





2. Press   to highlight "Date Search" or "Keyword Search" and press  to enter the desired search mode.
3. Enter the appropriate date or keyword and press  to confirm. The nearest record will be shown on the screen.
4. Press   to view relative records.

3.3.4 Data Editing and Deletion

1. To edit a record, highlight or view it and press  + . Press

 after editing to save the record.

2. To delete a record, highlight or



view it and press  + .

<<Schedule>>	
12/12 12	Delete record?
	Y/N






3. Press  to escape.






3.4 To Do List

To Do List can save Date, Category, Priority, Status (Done or To Be Done) and Content. Users can deal with the affairs quickly and clearly.


Choose "To Do List" from Organizer main menu. Press   to switch to browse the records between "Done" and "To Be Done".






There are 5 fields for data entry. The icons for data input are as follows:



-  Date
-  Category
-  Priority
-  Done/To Be Done
-  Content


	12/ 8/2005
	Personal
	1
	to be done
	


3.4.1 Data Entry

1. Press  to open a new record.


	12/20/2005
	Others
	1
	to be done
	meeting

2. Press   to choose the input item.






3. Press  to choose English or Vietnamese input mode.

4. Press  to lock the record.


Note: You must set password in System Setting before locking records.


5. After inputting data, press  to save the record.







3.4.2 Data Viewing

1. Highlight the desired record in the browse list and press  to view its contents.
2. Press   to view the unshown part of the content.
3. Press   to view the previous or next record.







3.4.3 Searching


1. Press  to search record.



2. Press   to highlight "Keyword Search" or "Date Search" and press  to enter the relevant search mode.
3. Enter keyword or the appropriate date and press  to view the nearest record.
4. Press   to view relative records.

3.4.4 Data Editing and Deletion


1. To edit a record, highlight or view it and press  + . Press  after editing to save the record.
2. To delete a record, highlight or view it and press  + .
3. Press  to escape.











3.5 Calendar

Calendar starts from 1901 to 2059.

1. Choose "Calendar" from Organizer main menu.




2. Press   to view the previous or next month.
3. Press  to search the desired date.
4. Those dates marked with " + " at the lower right corner are the dates with Schedule records.
5. To view Schedule record, highlight the corresponding date by pressing    , then press .












6. Press  to escape.


3.6 World Time

World Time displays the time in other cities.

1. Choose "World Time" from Organizer main menu.




2. Press  to set DST on or off.  will be shown to indicate DST on.
3. Press  or  to go to the "City" search screen.
4. Input the first letter of the city to search for the nearest city.
(e.g. for London, press )
5. Press  or  to highlight the desired city and press  to view its time.
6. Press  or  to view the previous or next city.
7. Press  to escape.









3.7 Local Time










User can set any city as the Local City, and set Alarm, Time and DST On/Off.

1. Choose "Local Time" from Organizer main menu.



2. To set Time/City/Alarm/DST, press  or . Then, highlight the desired item and press  to go to the relevant setting mode.
3. For "Time" setting, input the appropriate date and press  to shift to the time setting, enter the appropriate time, then press  to confirm.




4. For "City" setting, press   to scroll the browse list, choose a city as the local city and press  to confirm.
5. For "Alarm" setting, press   to select alarm on or off. Press   to shift to time setting, enter the appropriate time, then press  to confirm.
6. For "DST ON/OFF" setting, highlight this item in the Function menu, then press  to switch on/off DST.


Chapter 4 Calculator

4.1 Simple Calculator






This Calculator can perform the major functions of a simple calculator, such as arithmetic calculation, percentage calculation, memory functions, etc.

Choose "Simple Calculator" from Calculator main menu.






Press  to return to Calculator main menu.







4.1.1 Arithmetic Calculation

1. To calculate "1568+2389=?", enter "1568" and press  (i.e. "+") to add. Enter "2389" and then press  (i.e. "=") to get the result. The result is "3957".
2. To calculate "250 x 20%=?", enter "250" and press  (i.e. "x") to multiply. Then enter "20" and press  (i.e. "%"). The result is "50".
3. Press  to clear the numbers.

4.1.2 Indices and Roots

1. To calculate the multiple of 3, enter "3" and press  (i.e. "x") twice and press  to get the result "9". Press  once more to calculate "3 x 3 x 3=27" and so on.
2. To calculate "81=?", enter 81 and press  (i.e. $\sqrt{\quad}$) to find the square root. The result is "9".
3. Press  to clear the numbers.


4.1.3 Memory

1. Press  (i.e. "M+") to add the value in the memory.
2. Press  (i.e. "M-") to subtract the value from the memory.
3. Press  (i.e. "MR") to show the value stored in the memory.
4. Press  (i.e. "MC") to delete the value in the memory.

4.2 Scientific Calculator

This Calculator can perform the major functions of a scientific calculator. Other than arithmetic calculation, various functions such as radian calculation, trigonometry, etc. are also included.

Choose "Scientific Calculator" from Calculator main menu.

Press  to return to Calculator main menu.








4.2.1 Arithmetic Calculation

(Refer to 4.1.1 Arithmetic Calculation in Simple Calculator)

4.2.2 Indices and Roots

(Refer to 4.1.2 Indices and Roots in Simple Calculator)

4.2.3 Other Calculations






1. To calculate "1234+867+cos30=?", enter "1234" and press  (i.e. "+"), then enter "867" and press . Finally, enter "30" and press  (i.e. "cos"). Press  to get the result "2101.866025".
2. Press  to clear the numbers.


(You may use the same approach to calculate other functions.)






4.3 Unit Conversion

6 types of units commonly used in Viet. are provided for conversion. Two-way conversion is available for all units.

Choose "Unit Conversion" from Calculator main menu.

1. Press   to highlight the desired category and press  to confirm.
2. Press   to switch between upper and lower fields.



3. Press   to choose the unit for conversion.
4. Enter the value you want to convert in the selected field and press  to get the conversion result.
5. Press  to clear the result.
6. Press  to return to Calculator main menu.

Metres	1.
Centimetres	100.







4.4 Currency

25 currencies are collected and two-way conversion is available for all units. You can also set 3 user-defined currencies.

Choose "Currency Conversion" from Calculator main menu.






<<Currency Exchange>>	
1	Display
2	Set Rate
3	Conversion
4	User Define

4.4.1 Currency Display

1. Highlight "Display" in Currency Conversion submenu and press  to view the currencies.
2. Press   or   to scroll the currency list.
3. Press  to escape.







Australian dollar, AUD	1.0000000000
British pound, GBP	1.0000000000
Canadian dollar, CAD	

4.4.2 Rate Setting

1. Highlight "Set Rate" in Currency Conversion submenu and press  to confirm.
2. Press   to select the desired currency.
3. Enter the desired rate and press  to confirm the setting.
4. Press  to escape.







Australian dollar, AUD	1.
------------------------	----

4.4.3 Conversion

1. Highlight "Conversion" in Currency Conversion submenu and press  to confirm.
2. Press   to switch between upper and lower fields.
3. Press   to select the desired currency for conversion.
4. Enter the value you want to convert and press  to get the conversion result.

Australian dollar, AUD
0.
Australian dollar, AUD
0.

4.4.4 User Define



1. Highlight "User Define" in Currency Conversion submenu and press  to confirm.
2. Press   to highlight a user-defined currency and press . (User can also select a defined name to redefine it.)
3. Input the currency name and press  to save the input.
4. Press  to escape.





<<User Define>>	
1	User Define 1
2	User Define 2
3	User Define 3





4.5 Loan Interest


You can calculate the monthly payment and total interest, and inquiry for the interest paid, principal paid, total amount paid, and loan left are also available.





Choose "Loan Interest" from Calculator main menu.


1. Press   to choose the input item. The icons for data input are as follows:

-  Starting Year/Month
-  Mortgage
-  Annual Interest Rate
-  Loan Period





<<Loan Interest>>	
	2005/12
	0
	0 %
	0

2. Input value in the required items and press  to get the result.

<<Loan Interest>>	
	2005/12
	100
	0.25 %
	10

3. After getting the result, press  to inquire. Enter the desired Year and Month to calculate the Interest Paid, Principal Paid, Total Amount Paid, etc.

<<Result>>	
Monthly Payment	0.84388020066
Total Interest	1.26562407981

4. User can also press  +  after getting the result to edit the calculation.
5. Press  to clear data or escape.
6. Press  to return to Calculator main menu.

Chapter 5 System

5.1 Reference


Reference information such as Maths Formulae, English Name, Travel Guide, Size Equivalent, Voltage & Frequency and Telephone Code are provided for your reference.



Choose "Reference" from System main menu.



5.1.1 Maths Formulae


General Mathematical Formulae are categorized into different aspects for reference.


1. Choose "Maths Formulae" in Reference submenu.







2. Press   to choose line by line.


3. Press   to turn pages for choosing.

4. For example, choose "Algebra", press  to confirm.



5. Press   to choose line by line.


6. Press   to turn pages for choosing.



7. For example, choose "Inequality", then press  to confirm.

5.1.2 English Name



This function provides user with English Names of male and female for reference.



1. Choose "English Name" in Reference submenu.



2. Press   to choose Male or Female.

3. For example, choose "Male", press  to confirm.

4. Press   to view the record line by line.

5. Press   to view record page by page.
6. You can input English name directly.

```

Please input name:
AARON
ABBOTT
ABBY
ABE

```

7. Data will be shown automatically in the browse list.

5.1.3 Travel Guide






It provides the names of airlines, airports, temperature of different region, general information and travel reference.

1. Choose "Travel Guide" in Reference submenu.

```

<<Travel Guide>>
1 Airlines
2 Airports
3 Temperature
4 General Information






```

2. Press   to choose line by line.
3. Press   to turn pages for choosing.
4. For example, choose "Airlines", press  to confirm.

```

<<Airlines>>
AA American Airline
AC Air Canada
AF Air France
AI Air India

```

5. Press   to choose line by line.
6. Press   to turn pages for choosing.
7. Press  to escape.

5.1.4 Size Equivalent




It lists different sizes of the shirts and shoes for male and female in various regions for reference.

1. Choose "Size Equivalent" in Reference submenu.

```

<<Size Equivalent>>
1 Men's Shirt
2 Women's Shirt
3 Men's Shoes
4 Women's Shoes







```

2. Press   to choose line by line.
3. For example, choose "Men's Shirt", press  to confirm.

```

<<Men's Shirt>>
U.S.A : 13    13.5  14    14.5
Britain: 13    13.5  14    14.5
Europe : 33    34    35/36 37
Japan : 13    13.5  14    14.5








```


4. Press     to view content; press   to turn pages for inquiring.

5. Press  to escape.

5.1.5 Voltage & Frequency

The standard voltage and frequency used in various countries are listed.








1. Choose "Voltage & Frequency" in Reference submenu.
2. Press   to select the desired item, for example, choose "Europe", press  to confirm.
3. Press   to select the desired item, for example, choose "Austria", press  to confirm.
4. Press  to escape.




```
Austria
Voltage: 220/380V
Freq : 50Hz
```

5.1.6 Telephone Code

The telephone codes of various places are included for your distance calling.

1. Choose "Telephone Code" in Reference submenu.
2. Press   to select the desired item, for example, choose "Europe", press  to confirm.
3. Press   to select the desired item, for example, choose "Austria", press  to confirm.
4. Press  to escape.






```
<<Europe>>
AUSTRIA
INNSBRUCK
Code: 00 43 512
```

5.2 Games



There are 4 games for leisure and learning: Hangman, Snake, Apple Chess and Shooting Game.

Choose "Games" from Others main menu.

5.2.1 Hangman


1. Choose "Hangman" in Games submenu.
2. Press   to select "Normal" or "High" level and press  to start the game.


3. Enter the desired letter and press

 to confirm. Press  to view the result.



4. There are only 10 chances for guessing the correct answer. If a wrong letter is pressed, or press the pronunciation key once for hint, one chance will be deducted.




5. After guessing the word successfully within 10 chances, the explanation in Eng-Viet Dict. will be shown automatically. Press  to start a new game.








Note: The words in Normal level contain less than 10 letters, while the words in High level contain more than 10 letters.



5.2.2 Snake

1. Choose "Snake" in Games submenu.

2. Press   to select First, Second or Third Level and press  to start the game.

3. Press     to move the snake's head to catch the falling food. 100 points will be gained if catching a food.



4. Press  to pause the game, press  once more to resume the game.




5. You'll see "Congratulations!" when you become the winner.

6. If the snake hits the wall or itself, the game will be over.


7. Press  to escape.

5.2.3 Apple Chess

1. Choose "Apple Chess" in Games submenu.

2. Press   to select "Low" or "High" Level and press  to confirm.


- Press to move the checker to the desired pane to place and press to confirm.



- The player and the computer play the checker alternately. Only the checker placed in a blank pane and trapping the opponent's checkers is valid.
- The checkers trapped by the opponent's checkers will be taken over.
- Whoever occupies more panes will be the winner.
- Press to escape.

5.2.4 Shooting Game


- Choose "Shooting Game" in Games submenu.
- Press to select First, Second or Third Level and press to confirm.
- Press to move the machine gun to aim at a target or bomb and press to shoot. 100 points will be gained if shooting a target, and 200 points will be gained if shooting a bomb.
- Press to pause the game, press once more to resume the game.
- If a bomb explodes the machine gun, the game will be over.
- Press to escape.













5.3 USA Interview

A list of USA Interview questions are listed in both English and Vietnamese.

- Choose "USA Interview" in System submenu.







2. Press   to choose line by line.
3. For example, choose "General & Personal Question", press  to confirm.
4. Press   to view content; press   to turn pages for inquiring.
5. Press  for English pronunciation.
6. Press  to view the suggested answers.
7. Press  to escape.

GENERAL & PERSONAL QUESTION
 01. Hi; how are you? (How do
 you do? How are you doing?
 How have you been?)..
 -Chào bạn; bạn có khỏe

5.4 Display



User can select the display language of the unit.

1. Choose "Display" in System submenu.
2. Press   to select Vietnamese or English and press  to confirm. Or press the relevant numeric key directly.
3. Press  to escape without saving the setting.

<<Display Setting>>
 1 Vietnamese
 2 English

5.5 Memory Check

Showing space in percentage, which is vacant for data storage.


1. Choose "Memory Check" in System submenu.
2. Press  to view the number of records saved in different applications.
3. Press  to escape.

<<Memory Check>>
 Free Memory
 100%


5.6 Data Deletion

There are 8 items for deletion. They are Telephone Directory, Memorandum, Schedule, To Do List, User's Dictionary, Revision Test, Secret and Delete All. User can select any item to delete at one time.

1. Choose "Data Deletion" from System submenu.



2. Press or to select the item you want to delete and press .
3. A message "Delete All...?" appears. Press to retain all records. Press , a message "Confirm delete all?" appears. Press again to retain all records. Press again to delete all the records of the selected item.
4. Press to escape.




5.7 PC Link

For sending, receiving, backing up or restoring data, user can connect the unit to a personal computer with standard cable for PC Synchronization. This is applicable for data in Telephone Directory, Memorandum, Schedule and To Do List.

Note: Make sure the unit and the computer is well-connected before transmitting data.

1. Choose "PC Link" from System submenu.



2. Press to select the desired type of PC Link and press to confirm. (e.g. select "Send")
3. If "Send" is chosen, press or to select an item for transfer, then press to confirm.
4. Press to escape.

5.8 System Setting

There are 10 items in System Setting, i.e. Real Time Clock, Daily Alarm, Display Format, Sound On/Off, Speech Setting, Secret On/Off, Auto Power Off, Input Method, Repeat Setting and Chinese Display Mode.







Choose "System Setting" from System submenu.

5.8.1 Real Time Clock

You can set the real time of the unit.

1. Choose "Real Time Clock" in System Setting submenu.

<<Set Time>>
M/D/Y : 12/ 8/2005
2:04P







2. Press   to shift between the Year/Month/Date and enter the valid date.
3. Press   to shift to the time field and enter the valid time.
4. Press  to confirm the setting; press  to escape without saving the setting.

5.8.2 Daily Alarm

You can set the alarm time and switch on or off the alarm.

1. Choose "Daily Alarm" in System Setting submenu.

<<Set Daily Alarm>>
ON/OFF
:







2. Press   to choose the alarm ON or OFF.
3. Press   to shift to the alarm time field and enter the desired time.
4. Press  to save the setting; press  to escape without saving the setting.

5.8.3 Display Format

You can set the time and date format of the unit.

1. Choose "Display Format" in System Setting submenu.


<<Display Format>>
1.Time Format 12 24
2.Date Format M/D/Y D/M/Y







2. Press   to select the desired format item. (e.g. select "Time Format")
3. Press   to choose the desired display format for time and date. (e.g. choose "12" for Time Format)
4. Press  to save the setting.
5. Press  to escape without saving the setting.

5.8.4 Sound On/Off

User can set the keytone and alarm sound on or off.

1. Choose "Sound On/Off" in System Setting submenu.











2. Press   to select the setting item.
3. Press   to choose the keytone and alarm ON or OFF.
4. Press  to save the setting.
5. Press  to escape without saving the setting.

5.8.5 Speech Setting

User can set the speed and frequency of the speech of the unit.

1. Choose "Speech Setting" in System Setting submenu.




2. Press   to select the desired item ("Speed" and "Frequency") for setting.
3. Press   to adjust the speed or frequency of speech.
4. Press  to test the setting.
5. Press  to save the setting.
6. Press  to escape without saving the setting.

5.8.6 Secret On/Off

User can set password for the safety of the unit.

1. Choose "Secret On/Off" in System Setting submenu.



2. Enter a password with a maximum of 8 characters (English letters, numbers or symbols) and press **Enter =** to confirm.
3. Enter the password again for confirmation and press **Enter =**. The password will then be successfully set and secret will be switched on.

4. When a password is preset, after choosing "Secret On/Off", press **Up** **Down** to select "Secret Off" or "Clear Password". Press **Enter =** to enter the relevant mode.




5. Select "Secret Off" and enter the old password, press **Enter =**, the secret will be switched off.
6. Select "Clear Password" and enter the old password, press **Enter =**, the password will be cleared.
7. Press **Clear** to escape.

5.8.7 Auto Power Off

If no key is pressed within the default time, the unit will switch off automatically to save power. The default period is 3 minutes.

1. Choose "Auto Power Off" in System Setting submenu.








2. Press **Up** **Down** to adjust the power off period.
3. Press **Enter =** to save the setting.
4. Press **Clear** to escape without saving the setting.

5.8.8 Input Method

User can set Ordinary or Wisdom input method for the unit.

1. Choose "Input Method" in System Setting submenu.








2. Press   to select "Wisdom" or "Ordinary" and press  to confirm.
3. Press  to escape without saving the setting.

5.8.9 Repeat Setting

You can set the repeat times of the unit freely. The default is 3 times.

1. Choose "Repeat Setting" in System Setting submenu.







2. Press   to adjust the repeat times.
3. Press  to save the setting.
4. Press  to escape without saving the setting.

5.8.10 Chinese Display Mode

User can select Simple Chinese or Regular Chinese as the display language of the unit. The default is Regular Chinese.

1. Choose "Chinese Display Mode" in System Setting submenu.



2. Press   to select Simple Chinese or Regular Chinese and press  to confirm. Or press the relevant numeric key directly.
3. Press  to escape without saving the setting.

This manual may include technical inaccuracies or typographical errors. Changes are periodically made to the information contained herein; these changes will be incorporated in new editions of publication. We may make improvements and/ or changes in the product described in this publication at any time but do not undertake to notify customers of these changes.

Due to large database in use, though we have made great effort to proofread, we apologize for any defects found. Your invaluable comments are highly appreciated.

The Concise American Heritage[®] Dictionary, based on the Second College Edition. Copyright ©1983 by Houghton Mifflin Company. Published by Houghton Mifflin Company. No part of this database may be reproduced or otherwise used without prior written permission from the publisher unless such use is expressly permitted by applicable law.

No investigation has been made of common-law trademark rights in any word. Words that are known to have current trademark registrations are shown with an initial capital and are also identified as trademarks. The inclusion or exclusion of any word, or its capitalization, in this dictionary is not, however, an expression of the publisher's opinion as to whether or not it is subject to proprietary rights, nor is to be regarded as affecting the validity of any trademark.

American Heritage[®] is a registered trademark of Forbes Inc. Its use is pursuant to a license agreement with Forbes Inc.

ScanSoft and the ScanSoft logo are registered trademarks of ScanSoft, Inc. used under license.

85-A071-001101