

CONTENTS

INTRODUCTION	3
Keyboard	4
Direct function shortcuts	5
Control and editing keys	5
Icons Menu	6
POWER SUPPLY	7
SETUP MAIN MENU	9
1. Password	9
2. Tone	12
3. Date Format	12
4. Time Format	13
5. Local Time	14
6. Alarm On/Off	15
7. Daily Alarm	16
8. Memory Used	16
9. Display Language	17
DICTIONARY	18
General Dictionary Function	18
Advanced Word Recognition	20
Cross Search	21
Spell-Checker Vector Ultima™	22
USER'S DICTIONARY	23
IRREGULAR VERBS	25
AMERICAN IDIOMS	26

PHRASES	27
PC - LINK	28
TELEPHONE DIRECTORY	29
MEMO	31
SCHEDULE	32
CALENDAR	34
TIME	35
Home Time	36
World Time	36
ANNIVERSARY	37
CALCULATOR	39
ACCOUNT MANAGER	39
METRIC AND CURRENCY CONVERSION	42
Metric Conversion	42
Currency Conversion	43
GAMES	45
Master Mind	46
Hangman	46
DATA DELETION	47
AUTOMATIC SHUT-OFF	48

INTRODUCTION

Congratulations on purchasing the English-Russian Digital Dictionary & Business Organizer *Language Teacher® ER200D*. This extraordinary language assistant is loaded with such features as:

- *Main vocabulary of over 450,000 words, including general words and idioms, medical, technical, legal, business terms, as well as slang and general expressions*
- *128K bilingual business organizer comprising Telephone Directory, Schedule, Memo, and Anniversary List*
- *New words recording function for dictionary expansion*
- *Instant reverse translation*
- *Vector Ultima™ spell-checking system*
- *Advanced word recognition system*
- *200 most popular American idioms*
- *English irregular verbs*
- *Over 1000 topically arranged phrases*
- *Game center*
- *PC-Link for data exchange with PC*
- *Account manager*
- *Calendar*



- *Currency and Metric conversion*
- *Home and World Time*
- *Calculator*


Enjoy your *Language Teacher® ER200D* and make it your personal travel and business guide.




As continuous efforts are made by the manufacturer to improve quality and performance of the *Language Teacher®* products, some characteristics or the design of the actual device you purchased may slightly differ from their description in this manual.

Keyboard

The standard American QWERTY keyboard layout enhanced with additional Russian letters allows you to enter any word just in seconds.

English and Russian character sets and a numeric layout can be switched between in repeating sequence by pressing the  key. In the main dictionary, however, the input language selection is handled automatically to comply with the current source language, and the  key is disabled.

To access Russian letters “Э” and “Ъ”, as well as hyphen, period, and apostrophe, press and release  prior to using the corresponding key.

An additional symbols set is available through pressing +SYMB. Use  ^  to see more symbols. Press the indicated number key to insert a selected symbol.

Direct function shortcuts



Main Dictionary



Home and World Time



Calculator



Phrases



Telephone Directory



Setup Main Menu

VERB

Irregular Verbs

IDIOM

American Idioms

Control and editing keys



Page by screenful

SPELLER

Check spelling in main dictionary



Move cursor



Move cursor / scroll lines



Start a new line

DEL

Delete character or record



Enter



Switch English / Russian / Numeric



Toggle Insert / Overwrite



Enter space

↑+SYMB.

Show symbols (∨∧ for more)



Enable record editing

ESC

Close or clear screen

Computational symbols and operations are available when using the *Calculator* function.


Icons Menu

The *Language Teacher® ER200D* features a new start-up interface with functional icons, which visually organize and facilitate access to the dictionary's multiple sections.

The *Icons Menu* appears after system initialization or whenever you exit a section by pressing the ESC key. The upper portion of the *Icons Menu* includes, from left to right, top to bottom: *Dictionary*, *User's Dictionary*, *Irregular Verbs*, *Idioms*, *Phrases*, *PC-Link*.



Page down to reveal the middle screen, which contains the following icons: *Telephone Directory*, *Memo*, *Schedule*, *Calendar*, *Home and World Time*, *Anniversary*.



The bottom set of icons represents the sections *Calculator*, *Account Manager*, *Metric and Currency Conversion*, *Game*, *Data Deletion*, *Setup Main Menu*:



Use \wedge \vee keys to move between the *Icons Menu* screens. Use arrow keys to highlight icons of the displayed *Menu* portion. Press \downarrow to open the section whose icon is highlighted.

POWER SUPPLY

The *Language Teacher® ER200D* is powered by two main CR2032 batteries and a CR1220 memory backup battery.

- ◆ **Note:** After purchasing the *Language Teacher® ER200D* install the main batteries (included) as described below.

When the batteries become weak, a warning message will be displayed. In order to prevent a complete discharge of batteries and possible loss of data in RAM, replace the whole set of main batteries promptly. Do not mix old and new batteries.

- Press the ON/OFF key to turn the unit off.

- Remove the battery compartment cover by sliding it away from the unit.
- Use a small screwdriver to remove the metallic brace that holds batteries in place.
- Take out the old batteries and put in new ones.
- ◆ **Note:** Make sure to place both batteries so that the plus signs (+) are on top.
- Secure the batteries in place with the metallic brace.
- Put back the battery compartment cover by sliding it toward the unit. Make sure the cover sits in place properly.
- ◆ **Note:** You have 2 minutes to replace the batteries without risk of losing data stored in RAM. **Do not exceed the 2 min. limit! Neither manufacturer nor dealer may be held responsible for the loss of user's data.**
- ◆ **Note:** Never try to remove batteries from the translator when the power is on. This can seriously damage the device. If you experience difficulty turning the unit off, press the RESET button located on the back near the battery compartment cover to reinitialize the system.

During a system reset, press N at the prompt <CLEAR DATA? Y/N> or <ERROR! CLEAR? Y/N> to attempt preserving user's data and the customized system configuration. However, if RAM has been corrupted, or if you turn the dictionary on for the first time, you will have to press Y to reinitialize the system.



SETUP MAIN MENU

For best results and to ensure that you can fully employ all of the *Language Teacher® ER200D*'s diverse features, you have to familiarize yourself with options of the *Setup Main Menu*, which will allow you to adjust the device configuration to better suit your needs.

- *Password*
 - *Key Tone*
 - *Date Format*
 - *Time Format*
 - *Local Time*
 - *Alarm On/Off*
 - *Daily Alarm*
 - *Memory Used*
 - *Display Language*
- ♦ **Note:** All prompts and messages appear in English by default. To change the display language to Russian, start the customization from option 9. *Display Language*.

1. Password

- Press ON/OFF to turn the translator on.

- Press the  key on the keyboard or select the icon  on the bottom *Icons Menu*.

```
1 . PASSWORD
2 . KEY TONE
3 . DATE FORMAT
4 . TIME FORMAT
```


- Press 1 or make sure the *Password* line is highlighted and press ↵ to see the *Password* menu:

```
SET PASSWORD
CLEAR PASSWORD
```

- Select *Set Password* to open the *Password* setup screen.

```
ENTER NEW PASSWORD:
```


```
—
```

- Enter a password up to 8 characters long.
- Press ↵ to save the password and return to the *Password* menu. A key sign will appear in the upper left-hand corner of the screen indicating that user's records are password-protected.
- Press ESC or  to return to the *Setup* main menu.

- To change the password, re-open the *Password* menu and select the *Set Password* option.

ENTER OLD PASSWORD:

—

- Specify your password. If the input didn't match the current setting, the message *Wrong Password* will appear.
- If the input matched the actual password, the prompt will change to *New Password*. Type in a new password and press ↵ to save and return to the *Password* menu.
- Press ESC or  to return to the *Setup* main menu.
- To delete the password, thus removing the data protection, re-open the *Password* menu and select the *Clear Password* option.
- Specify your password at the prompt. If the input didn't match the current setting, the message *Wrong Password* will appear.
- If the input matched the actual password, the key sign will disappear, and the display will return to the *Password* menu. User's records will no longer be password-protected.
- ♦ **Note:** Always remember your password. If you forget it you will need to reset the dictionary, which will cause loss of user's data stored in RAM.

2. Key Tone

- On the *Setup* main menu, press the 2 key, or highlight the *Key Tone* line and press ↵ to enter the *Key Tone* setup.

SET KEY TONE

ON

OFF

- This feature is designed to produce an audible signal every time you press a key on the keyboard of the *Language Teacher®*. The *Key Tone* is activated by the system's default.
- Press ▼ or ▲ to move the highlight bar to OFF or ON, respectively.
- Press ↵ to confirm your setting and return to the *Setup* main menu. With the *Key Tone* turned on, an note sign is displayed on the right-hand side of the screen.

3. Date Format

- On the *Setup* main menu, press the 3 key, or highlight the *Date Format* line and press ↵ to enter the *Date Format* setup.

```

      SET DATE FORMAT
      DD/MM/YYYY
      MM/DD/YYYY
      YYYY/MM/DD
  
```

The day/month/year date format is chosen by default in the system.

- Use ▼▲ keys to highlight a desired format.
- Press ↵ to confirm your setting and return to the *Setup* main menu.

4. Time Format

- On the *Setup* main menu, press the 4 key, or highlight the *Time Format* line and press ↵ to enter the *Time Format* setup.

```

      SET TIME FORMAT
      24-HOUR
      12-HOUR
  
```

The 24-hour time format is chosen by default in the system.

- Use ▼▲ keys to highlight the desired format.
- Press ↵ to confirm your setting and return to the *Setup* main menu.

5. Local Time

- On the *Setup* main menu, move the highlight bar to option 5 and press ↵ to display the home city selection screen.

```

      ENTER FIRST LETTER
      FOR CITY OR COUNTRY

      CITY: _   COUNTRY:
  
```

- Select the field CITY or COUNTRY using the ◀▶ keys, and type a letter. Names of a city and country first on the alphabetical list in the selected category, as well as date and time, will appear on the screen. For example:

```

      MADRID, SPAIN
      01 / 01 / 1999 (FR)


      02 : 05 : 35 PM
  
```

- Use ▼▲ keys to move through the alphabetical list of cities, or use ^v to move by countries. Press ↵ to confirm your selection and display the date and time setup screen.

```

      01 / 01 / 1999

      08 : 06 AM
  
```

- Change values above the cursor by pressing appropriate number keys on the keyboard. Move the cursor with the arrow keys. If you prefer the 12-hour American time format, specify PM by pressing P or AM by pressing A in the last position.
- Press ↵ to save the settings. The previous screen will be shown reflecting the new settings.
- Press ESC or  to return to the *Setup* menu.

6. Alarm On/Off

- On the *Setup* main menu, move the highlight bar to option 6 and press ↵ to enter the *Alarm On/Off* setup.



- Use ▼▲ keys to turn the *Alarm* signal on or off. This setting affects both *Schedule* alarm and *Daily Alarm*.
- Press ↵ to leave the *Alarm On/Off* setup and return to the *Setup* main menu. With the *Alarm* turned on, a bell sign is displayed on the right-hand side of the screen.

7. Daily Alarm


- On the *Setup* main menu, move the highlight bar to option 7 and press ↵ to enter the *Daily Alarm* time setup.



- To set the alarm time, change values above the cursor by pressing the appropriate number keys on the keyboard. Move the cursor with the ◀▶ keys. If you prefer using the 12-hour American time format, specify PM by pressing P or AM by pressing A.
- Press ↵ to leave the *Daily Alarm* Setup and return to the *Setup* main menu.

8. Memory Used

- On the *Setup* main menu, move the highlight bar to option 8 and press ↵ to open the *Memory Used* chart.



- Press ESC to return to the *Setup* main menu.

9. Display Language

- On the *Setup* main menu, move the highlight bar to option 9.

```
6.ALARM ON/OFF
7.SET DAILY ALARM
8.MEMORY USED
9.DISPLAY LANGUAGE
```

- Press the \downarrow key.

```
SET DISPLAY LANGUAGE
ENGLISH
RUSSIAN
```

- Highlight the RUSSIAN line and press \downarrow . The options names will change to Russian.



```
ЯЗЫК СООБЩЕНИЙ
АНГЛИЙСКИЙ
РУССКИЙ
```

- Press ESC to return to the *Setup* main menu. Now all messages will appear in Russian.

DICTIONARY

The *Language Teacher® ER200D* contains the most advanced English-Russian and Russian-English electronic dictionaries on the market. In order to fully utilize the potential of this dictionary carefully read this section of the User's Guide.

General Dictionary Function

- Press the ON/OFF key to turn the dictionary on.
- Press the  key on the keyboard or select the icon  on the top *Icons Menu* to enter the main *Dictionary* menu.



- Select a translation direction by moving the highlight bar to the corresponding icon, and press \downarrow .

```
ENGLISH->RUSSIAN
```

- ◆ **Note:** To reverse the translation direction, press ESC to exit to the *Dictionary* menu and select the opposite icon.

- Using the keyboard enter the word you want to have translated.

Suppose you want to translate the English word ADVENTURE into Russian.

```

ENGLISH->RUSSIAN

ADVENTURE
ADVENTURE
  
```

- ♦ **Note:** Use \uparrow + \downarrow to switch between the *Insert* and *Overwrite* input options, DEL to delete a character, ESC to clear the screen.
- Press \downarrow to display the dictionary entry.

```

ADVENTURE
A
ПРИКЛЮЧЕНЧЕСКИЙ;
N
  
```

- Press the \downarrow key to see more translations of the word ADVENTURE. To scroll back up, use \uparrow .

Words of the same spelling are contained within one entry. The translations are organized under appropriate part of speech abbreviations. Within a part of speech, translations are separated by semicolons.

Individual translations or meanings may include indicating material, for example geographical labels, field labels, style and usage labels and other sense-differentiating information in parentheses (AMERICAN) or in square brackets [COLLOQUIAL].

- Press the \vee or \wedge key to go to the alphabetically next or previous entry, respectively.
- ♦ **Note:** To translate another word in the same dictionary, start typing, and the input screen appears automatically.
- ♦ **Note:** Press ESC to return to the input screen.

Advanced Word Recognition

Your *Language Teacher® ER200D* is equipped with an *Advanced Word Recognition* feature. While you are typing the word you want to translate, a word closest to it in spelling appears on the screen's bottom line. If the desired word appeared before you finished typing, press \downarrow to see its translations.

- Start typing, for example, UMBRELLA in the English-Russian dictionary. When you reach the letter O the word appears at the bottom.

```

ENGLISH->RUSSIAN

UMBRE
UMBRELLA
  
```

- Press \downarrow to display the translations.

```

UMBRELLA
N
ЗОНТ; ЗОНТИК; БАРПАЖ
  
```

Proper usage of this function allows you to accelerate your work while translating larger texts.

Cross Search

Your *Language Teacher® ER200D* is equipped with a *Cross Search* function, which provides an instant reverse translation for all words in the main *Dictionary*.

- Type, for example, FIDELITY in the English-Russian dictionary and press ↵ to see the translations.

```
FIDELITY
N
БЕПНОСТЬ; ТОЧНОСТЬ
```

- Press ► to highlight the first translation, then use any arrow key to highlight a word of your choice, for example:

```
FIDELITY
N
БЕПНОСТЬ; ТОЧНОСТЬ
```

- Press ↵ for an instant reverse translation of the highlighted word:

```
БЕПНОСТЬ
N
FAITHFULNESS; FAITH;
LOYALTY; TRUSTINESS;
```

- To make another *Cross Search*, repeat steps 2 and 3. You may use this feature up to 20 times during one session.
- ♦ **Note:** Pressing ESC returns one step back in a series of reverse translations.

Spell-Checker Vector Ultima™

The spelling checker Vector Ultima™ is one of the most advanced English proofing tools on the market. It comes in handy when you are unsure of a word's exact spelling.

- Type, for example, ROTEISHN for *rotation*.

```
ENGLISH->RUSSIAN

ROTEISHN
```

- Press SPELLER. A list of suggestions is displayed on the screen.

```
ROGUISH
ROSES
ROSIN
ROTATION
```


- Press the ▼ key to move the highlight bar to the word ROTATION.
- Press the ↵ key to display the translations.


ROTATION
N
ВРАЩЕНИЕ;
ЧЕРЕДОВАНИЕ; ПОВОРОТ

- ♦ **Note:** If the spelling checker is unable to suggest alternative words, the message WORD NOT FOUND will be shown.

USER'S DICTIONARY

The *Language Teacher® ER200D* allows you to create your own vocabulary which automatically links to the main dictionary.

- Select the icon  on the top *Icons Menu* to enter the *User's Dictionary* menu.




- Select a translation direction by highlighting the corresponding icon and pressing ↵.
- ♦ **Note:** If a *Password* has been set up in the *Setup* main menu, you will be prompted to enter the valid password.

E : —
R : —

- Fill out the record, using the ◀▶ keys to move the cursor within a line, the ▼▲ keys to alternate between *English* and *Russian* lines (you may also press ↵ to move to the lower line). See section *Keyboard* p.4 for editing instructions and control keys assignments. Press ↵ while on the bottom line to save the record.
- **Note:** The input language is adjusted automatically.
- List existing records with the ^v keys.
- To change an existing record, press ↑+▶.
- To open a new record template while an existing record is being displayed in the viewing mode, press ESC.
- ♦ **Note:** If you press ESC after editing, you will be prompted to decide whether the new record or changes to an old record are to be saved.
- To delete a record, press DEL and confirm the displayed prompt.
- To open a *User's Dictionary* record from the main *Dictionary*, enter your record's headword **in full** on the input screen of the appropriate main *Dictionary*, and press ↵.

IRREGULAR VERBS

All commonly used English irregular verbs are stored in the *Language Teacher® ER200D's Irregular Verbs* directory in the alphabetical order.

- Select the icon  on the top *Icons Menu* to open the input screen of the *Irregular Verbs* section.

VERBS

 —

- Start typing the verb whose basic forms and a Russian translation you want to see.

VERBS

 BRI_
BRING

- Press \downarrow when the desired verb appears on the bottom line.


BRING; BROUGHT;
BROUGHT
ПРИНОСИТЬ

- Use \vee and \wedge keys to page through records.
- Use \blacktriangledown and \blacktriangle keys to scroll a record, if necessary.

You may use the *Cross Search* feature to display the main dictionary entries for both English and Russian verbs. Refer to the *Dictionary* section for details.

AMERICAN IDIOMS

Over 200 popular American idioms and their Russian equivalents or translations are included in the *Language Teacher® ER200D's Idioms* directory. The idioms are listed in the alphabetical order.

- Select the icon  on the top *Icons Menu* to open the input screen of the *Idioms* section.

IDIOMS

 —

- Start typing an idiom, for example:

IDIOMS

 BAK
BAKER'S DOZEN

- Press \downarrow when the desired idiom appears on the bottom line.



BAKER'S DOZEN
ЧЕРТОВА ДЮЖИНА

- Use \vee and \wedge keys to page through records.
- Use \blacktriangledown and \blacktriangle keys to scroll a record, if necessary.

You may use the *Cross Search* feature to display the main dictionary entries for both English and Russian words. Refer to the *Dictionary* section for details.

PHRASES

There are over 1000 conversational phrases stored in the *Language Teacher® ER200D*'s memory. For your convenience, they have been divided into topical categories listed below:

- | | |
|-----------------------------|----------------------------|
| 1. <i>Conversation</i> | 7. <i>Communication</i> |
| 2. <i>Traveling</i> | 8. <i>At the Bank</i> |
| 3. <i>Hotel</i> | 9. <i>Transport</i> |
| 4. <i>In the restaurant</i> | 10. <i>Health</i> |
| 5. <i>Shopping</i> | 11. <i>Beauty Care</i> |
| 6. <i>Sightseeing</i> | 12. <i>Call for Police</i> |
- Press the  key on the keyboard or select the icon  on the top *Icons Menu* to open the *Phrases* menu.

```

1 . CONVERSATION
2 . TRAVELING
3 . HOTEL
4 . IN THE RESTAURANT
  
```

- Highlight a topic using the \blacktriangledown \blacktriangle keys and press \downarrow . For example, select 4. *In the Restaurant*.


```

4A . APPOINTMENT
4B . ORDERING FOOD
4C . SERVICE
4D . PAYMENT
  
```

- Select an episode.
 - Use \vee and \wedge keys to list phrases up and down.
 - Use \blacktriangledown and \blacktriangle keys for scrolling.
- You may use the *Cross Search* feature to display the main dictionary entries for both English and Russian words. Refer to the *Dictionary* section for details.

PC - LINK

Using the *Language Teacher®* PC-Link cable (to be purchased separately) and the LT *ER200D* link software, you may transfer data from the organizer sections of your *Language Teacher® ER200D* to a personal computer and back.

- Connect the unit to a PC by the optionally supplied cable.
- Select the icon  on the top *Icons Menu* to open the menu of the *PC-Link* section.

```

1. PERSONAL TELEPHONE
2. BUSINESS TELEPHONE
3. SCHEDULE
4. MEMORANDUM

```

- Select a section for data transfer, for example:

```



3. SCHEDULE
-----
SEND
RECEIVE


```


- Select a transfer mode: *Send* or *Receive*.
- Start the *ER200D* link application on the PC and choose the transfer mode complementing the unit's transfer mode.
- Start the receiving device first, then the sending one.
- If the communication was successful, number of records transferred will be reported by the *ER200D* link program.

TELEPHONE DIRECTORY

You may store names, telephone numbers, and addresses in the *Telephone Directory* in English and Russian languages, view, delete, edit entries, and lock them with your password.

- Press the  key on the keyboard or select the icon  on the middle *Icons Menu* to open the *Telephone Directory*.



- Using the ► or ◀ key highlight one of the icons representing parts of the *Telephone Directory*, e.g. , and press ↵. A new record template opens automatically.
- ♦ **Note:** If a *Password* has been set up in the *Setup* main menu, you will be prompted to enter the current password.

```

NAME : _
TEL . :
FAX :
E-MAIL :


```

- Fill out the record, using the ◀► keys to move the cursor within a line, the ▼▲ keys to change lines (↵ to move to the lower line). See section *Keyboard* p.4 for editing instructions and control keys assignments. Press ↵ while on the bottom line to save the record.
- ♦ **Note:** You may enter information in the English or Russian language. To switch between them and a numeric layout in sequence, press the ⇄ key.
- List existing records with the ^v keys.

- To change an existing record, press **↑+▶**.
- To open a new record while an existing record is being displayed in the viewing mode, press ESC.
- ♦ **Note:** If you press ESC after editing, you will be prompted to decide whether the new record or changes to an old record are to be saved.
- To delete a record, press DEL and confirm the displayed prompt.

MEMO

Section *Memo* of your *Language Teacher® ER200D* provides you with a handy storage for short notes and messages.

- Select the icon  on the middle *Icons Menu* to open a new *Memo* record template.
- ♦ **Note:** If a *Password* has been set up in the *Setup* main menu, you will be prompted to enter the current password.

TITLE : _ CONTENT :


- Fill out the record, using the **◀▶** keys to move the cursor within a line, the **▼▲** keys to change between *Title* and *Content* (or press **↓** to move to the lower line). See section *Keyboard* p.4 for editing

instructions and control keys assignments. Press **↓** on the *Content* line to save the record.

- ♦ **Note:** You may enter information in the English or Russian language. To switch between them and a numeric layout in sequence, press the **↔** key.
- List existing records with the **^v** keys.
- To change an existing record, press **↑+▶**.
- To open a new record while an existing record is being displayed in the viewing mode, press ESC.
- ♦ **Note:** If you press ESC after editing, you will be prompted to decide whether the new record or changes to an old record are to be saved.
- To delete a record, press DEL and confirm the displayed prompt.

SCHEDULE

You can effectively plan out your time using the *Schedule* section of your *Language Teacher® ER200D*. You may enter records in English and Russian, edit, search, or delete them.

- Select the icon  on the middle *Icons Menu* to open a new *Schedule* record template.
- ♦ **Note:** If a *Password* has been set up in the *Setup* main menu, you will be prompted to enter the current password.


```

DATE: 01/01/1999
START TIME: 08:26A
END TIME: 08:26A
AFFAIR:


```

- ♦ **Note:** The first two lines show the current date and the current time in the format customized in the *Setup* menu. Should you need to change the format, go to the *Setup* menu and make the required modifications.
- Press ▼ or ⌵ to move to the next line when creating a record with today's date. Otherwise, type a new date with the number keys, using the ◀▶ keys if needed to move the cursor.
- Specify the starting and ending time of the affair on the second and third line, respectively. In the 12-hour format the letter A stands for AM, P for PM.
- ♦ **Note:** Use ▼▲ keys if necessary to move to the next or previous line (you may also press ⌵ for the next line). If date or time specified is invalid, the record will not be saved.
- Fill out the *Affair* line, using the ◀▶ keys to move the cursor within the line. See section *Keyboard* p.4 for editing instructions and control keys assignments.
- On the last line *Alarm* indicate by entering Y or N whether an audible signal should announce the start time of the affair. In order for this to happen, both the *Schedule* signal and the general *Alarm* (option 6 of the *Setup* main menu) must be turned on.
- Press ⌵ on the *Alarm* line to save the record.

- ♦ **Note:** You may enter information in the English or Russian language. To switch between them and a numeric layout in sequence, press the ⇄ key.
- List existing records with the ^v keys.
- To change an existing record, press ↑+▶.
- To open a new record while an existing record is being displayed in the viewing mode, press ESC.
- ♦ **Note:** If you press ESC after editing, you will be prompted to decide whether the new record or changes to an old record are to be saved.
- To delete a record, press DEL and confirm the displayed prompt.
- ♦ **Note:** You can use the *Calendar* section (see p.34) to open existing *Schedule* records, dates of which are marked on the *Calendar* with an apostrophe.

CALENDAR

The *Calendar* gives you a convenient way to search and open the *Schedule* and *Anniversary* records.

- Select the icon  on the middle *Icons Menu* to enter the *Calendar* screen.


01/01/1999					FR		
					1	2'	
3	4	5	6	7	8	9	
10	11	12	13	14	15	16	


- **Note:** The *Calendar* opens on the current date shown in the upper left-hand corner of the screen. The date format depends on the option chosen in the *Setup* main menu. Dates of existing *Schedule* and *Anniversary* records are apostrophized or framed, respectively.
- Move by date using the ◀▶▼▲ keys. Move by months with the ^v keys.
- To open either a *Schedule* or an *Anniversary* record, the date of which is marked on the *Calendar*, highlight this date and press ↵.
- **Note:** If the selected date applies to both *Schedule* and *Anniversary*, an intermediate menu will be shown:

ANNIVERSARY
SCHEDULE


Highlight an option and press ↵ to open the appropriate record.

TIME

- Press the ⌚ key on the keyboard or select the icon  on the middle *Icons Menu*.




Home Time

- Select  on the *Time* menu.

NEW YORK, USA
01 / 01 / 1999 (FR)
08 : 25 : 36

- ♦ **Note:** New York, USA is chosen by default. Should you need to select another city, or modify the date and time or their display format, go to the *Setup* main menu and make the required changes.

World Time

- Select  on the *Time* menu. The following prompt will be displayed:

ENTER FIRST LETTER
FOR CITY OR COUNTRY
CITY: _ COUNTRY: _

- Select the field CITY or COUNTRY with the ◀▶ keys and specify a letter. Names of the city and country first on the alphabetical list in the selected category, as well as date and time, will appear on the screen. For example, type 'P' for city.


```
P.MORESBY, P.N.GUINEA
01 / 01 / 1999 (FR)
10 : 28 : 35 PM
```

- Use ▼▲ keys to move through the alphabetical list of cities, ^ v to move by countries. For example, press ▼ twice to reach Paris, France:

```
PARIS, FRANCE
01 / 01 / 1999 (FR)
03 : 28 : 43 PM
```

ANNIVERSARY

In the *Anniversary* section of your *Language Teacher* ® ER200D you can conveniently store information on birthdays, various commemorative dates and other recurrent events.

- Select the icon  on the middle *Icons Menu* to open a new *Anniversary* record template.

- ♦ **Note:** If a *Password* has been set up in the *Setup* main menu, you will be prompted to enter the current password.



```
DATE : 01 / 01
CONTENT : _
```

- ♦ **Note:** The first line shows the current date in the format selected in the *Setup* menu. Should you need to change the format, go to the *Setup* menu and make the required modifications.
- Press ▼ or ⏴ to move to the next line when creating a record with today's date. Otherwise, type a new date with the number keys, using the ◀▶ keys if needed to move the cursor.
- Fill out the *Content* line using the ◀▶ keys to move the cursor within the line. See section *Keyboard* p.4 for editing instructions and control keys assignments. Press ⏴ on the *Content* line to save the record.
- ♦ **Note:** If date specified is invalid, the record will not be saved.
- ♦ **Note:** You may enter information in the English or Russian language. To switch between them and a numeric layout in sequence, press the ⇄ key.
- List existing records with the ^ v keys.
- To change an existing record, press ⏶+▶.
- To open a new record while an existing record is being displayed in the viewing mode, press ESC.

- ♦ **Note:** If you press ESC after editing, you will be prompted to decide whether the new record or changes to an old record are to be saved.
- To delete a record, press DEL and confirm the displayed prompt.
- ♦ **Note:** You can use the *Calendar* section (see p.34) to open existing *Anniversary* records, dates of which are framed on the *Calendar*.

CALCULATOR

The *Calculator* is one of the *Language Teacher® ER200D*'s features designed for your convenience.

- Press the  key on the keyboard or select the icon  on the bottom *Icons Menu*.


CALCULATOR

0.

- Use this function as a regular pocket calculator.

ACCOUNT MANAGER

The *Account Manager* section of the *Language Teacher® ER200D* allows you to keep track of your banking transactions.

- Select the icon  on the bottom *Icons Menu* to enter the *Account Manager*.

ACCOUNT MANAGER

ACCOUNT

DEPOSIT


WITHDRAWAL


- Using the ▼▲ highlight one of the options: *Account*, *Deposit*, *Withdrawal*, or *Transfer*, and press ↵ to open a new record template.
- ♦ **Note:** If a *Password* has been set up in the *Setup* main menu, you will be prompted to enter the current password.
- Enter data using the ◀▶ keys to move the cursor within a line, the ▼▲ keys to change lines (↵ to move to the next line). See section *Keyboard* p.4 for editing instructions and control keys assignments. Press ↵ while on the bottom line to save the record.
- In the *Date* line of any record press ▼ to move to the next line when creating a record with today's date. Otherwise, type a new date with the number keys using the ◀▶ keys if needed to move the cursor.
- ♦ **Note:** If date specified is invalid, the record will not be saved.
- Specify an account number when filling out lines *A/C NO*, *FR. A/C*, *TO A/C*.
- ♦ **Note:** If an account number line is left empty or refers to an invalid account (or, in the *Account* option, if numbers are duplicated), the record will not be saved.

- *Amount* refers to money sums used to calculate the current account balance in the option *Balance* of the *Account Manager* menu. A withdrawal up to the negative balance over specified *Credit Limit* will generate a warning message.
- Lines *Owner*, *Details* are for reference and can be filled out as needed.
- ♦ **Note:** You may enter information in the English or Russian language. To switch between them and a numeric layout in sequence, press the \leftrightarrow key.
- List existing records with the $\wedge \vee$ keys.
- To change an existing record, press $\uparrow + \blacktriangleright$.
- To open a new record while an existing record is being displayed in the viewing mode, press ESC.
- ♦ **Note:** If you press ESC after editing, you will be prompted to decide whether the new record or changes to an old record are to be saved.
- To delete a record, press DEL and confirm the displayed prompt.
- To inquire on the current balances of existing accounts, open the last menu option *Balance*.

A/C NO.:	3 4 4	7 5 6	8 8 3
\$:	3 5 5 0 .		
A/C NO.:	9 9 3	7 4 5	8 7 6
\$:	- 6 . 3 0		


METRIC AND CURRENCY CONVERSION


- Select the icon  on the bottom *Icons Menu* to open the *Metric and Currency Conversion* menu.



Metric Conversion

With your *Language Teacher® ER200D* you may easily convert measurements from the American system into the metric system commonly used in Europe and vice versa.

- Select the icon  to enter the *Metric Conversion* section.



- Use $\blacktriangledown \blacktriangle$ keys to highlight an option, e.g. *Length*, and press \blacktriangledown :

LENGTH	
FT<>M	
YD<>M	
MILE<>KM	

- Select a unit pair, for example, yard<>meter

LENGTH	
YD :	0.
M :	0.00

- Choose a source measurement unit, moving the highlight bar with the ▼▲ keys.
- Enter a numeric value in the highlighted field. Its equivalent will be calculated instantly and shown on the other line.
- Use ESC to return to the previous screen.

Currency Conversion

The *Currency Conversion* function built into your *Language Teacher® ER200D* allows you to instantly convert amounts in 12 currencies.

- Select the icon  to enter the *Currency Conversion* section.

CURRENCY CONVERSION
SET CURRENCY NAME
SET CURRENCY RATE
CONVERSION

- To change or add a currency label, select the option *Set Currency Name*.

SET CURRENCY NAME
USD
RBL
GBP

- Highlight a pre-specified currency abbreviation or one of reserve lines at the bottom (marked * * *) and press ↵.
- Type in a new currency name and press ↵ to save. Repeat the procedure if necessary.
- Press ESC to return to the *Currency Conversion* menu.
- Select the option *Set Currency Rate*.

SET CURRENCY RATE	
USD	1.000
RBL	1.000
GBP	1.000


- To specify a rate for a currency, highlight the corresponding line using the ▼▲ keys and press ↵, for example:


SET CURRENCY RATE	
RBL	1.000
	0.

- Type in an exchange rate based, for example, on the US dollar (the rate of which has to remain at 1.000), pressing the ↵ key to save the value.
- Specify exchange rates for other currencies.
- Press ESC to return to the *Currency Conversion* menu.
- Select the option *Conversion*.
- Highlight a currency name using the ▼▲ keys and press ↵.
- Enter an amount for conversion and press ↵ to see equivalents in other currencies.


GAMES


The *Language Teacher® ER200D* features a number guessing game *Master Mind* and a learning game *Hangman*, which improves your spelling skills and enhances your personal vocabulary

- Select the icon  on the bottom *Icons Menu* to open the *Games* menu.



Master Mind


- On the *Games* menu, select the icon  to enter the *Master Mind* menu.
- Choose a difficulty level. On the high level the number may contain repeated digits.
You have 12 attempts to guess a four-digit number.
- Type in a number and touch ↵ to see the result of the guess on the right-hand side of the screen.




A solid circle means that one of the digits you entered is present in the number but occupies another position. A ring indicates the presence of a correctly guessed digit in its proper position.

If you succeed or use up all tries, a corresponding message will be shown.

Hangman

- On the *Games* menu, select the icon  to start the *Hangman Word Game*.




- Enter letters trying to guess the word. The correctly guessed letters appear in place of question marks in their actual positions in the word. The missed letters are shown for reference on the dash line. An element is added to the picture at right with every non-repeated missed letter.

When the game ends, the message *Congratulation!* or *You lost!*, depending on the outcome, appears on the screen for a second. If you could not guess the word, the translation of the word is also displayed. Press ESC to start a new game.

DATA DELETION

Using the *Data Deletion* function of the *Language Teacher® ER200D* you can free up the memory by deleting user's data from selected organizer sections.

- Select the icon  on the bottom *Icons Menu* to enter the *Data Deletion* menu.



- Select an option and confirm the displayed prompt.

AUTOMATIC SHUT-OFF

In order to conserve the power of batteries, the *Language Teacher® ER200D* automatically shuts the power off if none of the keys has been pressed for three minutes.